



# Single room control system

## FSL-CONTROL III

for decentralised ventilation units from software version 6.0



**TROX<sup>®</sup> TECHNIK**  
The art of handling air

TROX GmbH  
Heinrich-Trox-Platz  
47504 Neukirchen-Vluyn, Germany  
Germany  
Phone: +49 (0) 2845 2020  
Fax: +49 2845 202-265  
E-mail: [trox@trox.de](mailto:trox@trox.de)  
Internet: <http://www.troxtechnik.com>

A00000086251, 2, GB/en  
12/2021

© TROX GmbH 2020

## General information

### About this manual

This manual enables personnel to correctly install and configure FSL-CONTROL III for the control of TROX decentralised ventilation units.

This manual is intended for use by network administrators, instructed persons, and qualified electricians or air conditioning technicians.

It is essential that these individuals read and fully understand this manual before starting any work. The basic prerequisite for safe working is to comply with the safety notes and all instructions in this manual.

The local regulations for health and safety at work and the general safety regulations for the area of application of the ventilation unit also apply.

This manual must be given to the system owner when handing over the system. The system owner must include the manual with the system documentation. The manual must be kept in a place that is accessible at all times.

Illustrations in this manual are mainly for information and may differ from the actual design.

### Other applicable documentation

- Operating and installation manual for the decentralised ventilation unit
- Project-specific documents (if any)

### Copyright

This document, including all illustrations, is protected by copyright and pertains only to the corresponding product.

Any use without our consent may be an infringement of copyright, and the violator will be held liable for any damage.

This applies in particular to:

- Publishing content
- Copying content
- Translating content
- Microcopying content
- Saving content to electronic systems and editing it

### TROX Technical Service

To ensure that your request is processed as quickly as possible, please keep the following information ready:

- Product name
- TROX order number
- Delivery date
- Brief description of the fault

Online	<a href="http://www.troxtechnik.com">www.troxtechnik.com</a>
Phone	+49 2845 202-400

### Limitation of liability

The information in this manual has been compiled with reference to the applicable standards and guidelines, the state of the art, and our expertise and experience of many years.

The manufacturer does not accept any liability for damages resulting from:

- Non-compliance with this manual
- Incorrect use
- Operation or handling by untrained individuals
- Unauthorised modifications
- Technical changes
- Use of non-approved replacement parts

The actual scope of delivery may differ from the information in this manual for bespoke constructions, additional order options or as a result of recent technical changes.

The obligations agreed in the order, the general terms and conditions, the manufacturer's terms of delivery, and the legal regulations in effect at the time the contract is signed shall apply.

We reserve the right to make technical changes.

### Warranty claims

The provisions of the respective delivery terms apply to warranty claims. For purchase orders placed with TROX GmbH, these are the regulations in section "VI. Warranty claims" of the Delivery and Payment Terms of TROX GmbH, see [www.trox.de/en/](http://www.trox.de/en/).

<b>1</b>	<b>Safety</b> .....	<b>5</b>		
1.1	Symbols used in this manual .....	5		
1.2	Correct use .....	5		
1.3	Safety signs .....	5		
1.4	Electric shock hazard .....	6		
1.5	Qualified staff .....	6		
<b>2</b>	<b>Making electrical connections</b> .....	<b>7</b>		
2.1	Wiring .....	7		
2.1.1	Connection of the supply voltage .....	7		
2.1.2	Connection of the control panel .....	7		
2.1.3	Connection of room temperature sensor .....	9		
2.1.4	Connection of external inputs and outputs .....	10		
2.1.5	Communication FSL-CONTROL III .....	11		
2.2	Connection to the central building management system (central BMS) .....	15		
2.2.1	Modbus RTU / BACnet MS/TP .....	15		
2.2.2	Modbus TCP / BACnet IP .....	15		
<b>3</b>	<b>Control of the ventilation unit</b> .....	<b>17</b>		
3.1	FSL-CONTROL III control system .....	17		
3.1.1	Control components .....	17		
3.1.2	Functional description .....	17		
<b>4</b>	<b>Description of software</b> .....	<b>27</b>		
4.1	Start screen – Diagnostics .....	28		
4.2	Diagnostics menu .....	29		
4.2.1	'Device status → diagnostics' .....	29		
4.2.2	'Temperature control → diagnostics' .....	30		
4.2.3	'Fan control → diagnostics' .....	31		
4.2.4	'Alarms and filter reset → diagnostics' .....	32		
4.2.5	'Diagnostics → Remaining run times*+' .....	33		
4.2.6	'Diagnostics → IO connections*+' .....	34		
4.2.7	'Diagnostics → Secondary air addition*+' .....	35		
4.3	Configuration menu .....	36		
4.3.1	'Configuration → Device description' .....	36		
4.3.2	'Configuration → Temperature control' .....	36		
4.3.3	'Configuration → Clock and timer' .....	37		
4.3.4	'Configuration → Fan control' .....	38		
4.3.5	'Configuration → Interfaces' .....	39		
4.3.6	'Configuration → Temperature control*+' .....	41		
4.3.7	'Configuration → Air control*+' .....	43		
4.3.8	'Configuration → Secondary air addition damper*+' .....	44		
4.3.9	'Configuration → Secondary air addition fan*+' .....	45		
4.3.10	'Configuration → Characteristics*+' .....	46		
4.3.11	'Configuration → IO connections*+' .....	49		
4.3.12	'Configuration → Device configuration*+' .....	52		
4.3.13	'Configuration → Functions*+' .....	53		
4.3.14	'Configuration → Alarms*+' .....	54		
4.3.15	'Configuration → Frost protection*+' .....	55		
4.3.16	'Configuration → Control panel*+' .....	56		
4.3.17	'Configuration → Options*+' .....	56		
4.4	Manual control menu .....	57		
4.4.1	'Manual control → Commands' .....	57		
4.5	Menu for connection to central BMS .....	58		
4.5.1	Connection to the central BMS via Modbus .....	58		
4.5.2	'Connection to central BMS → Device => central BMS' .....	59		
4.5.3	'Connection to central BMS → Central BMS => device' .....	63		
4.5.4	Connection to central BMS via BACnet .....	65		
<b>5</b>	<b>Control panel</b> .....	<b>75</b>		
5.1	Overview of control panels .....	75		
5.2	Control panel settings .....	77		
<b>6</b>	<b>Index</b> .....	<b>78</b>		

# 1 Safety

## 1.1 Symbols used in this manual

### Safety notes

Symbols are used in this manual to alert readers to areas of potential hazard. Signal words express the degree of the hazard.

Comply with all safety instructions and proceed carefully to avoid accidents, injuries and damage to property.

#### **DANGER!**

Imminently hazardous situation which, if not avoided, will result in death or serious injury.

#### **WARNING!**

Potentially hazardous situation which, if not avoided, may result in death or serious injury.

#### **CAUTION!**

Potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

#### **NOTICE!**

Potentially hazardous situation which, if not avoided, may result in property damage.

#### **ENVIRONMENT!**

Environmental pollution hazard.

### Safety notes as part of instructions

Safety notes may refer to individual instructions. In this case, safety notes will be included in the instructions and hence facilitate following the instructions. The above listed signal words will be used.

Example:

1. ▶ Loosen the screw.

2. ▶

 **CAUTION!**  
**Danger of finger entrapment when closing the lid.**

Be careful when closing the lid.

3. ▶ Tighten the screw.





### Tips and recommendations



*Useful tips and recommendations as well as information for efficient and fault-free operation.*

### Additional markers

In order to highlight instructions, results, lists, references and other elements, the following markers are used in this manual:

Marker	Explanation
 1., 2., 3. ...	Step-by-step instructions
	Results of actions
	References to sections in this manual and to other applicable documents
	Lists without a defined sequence
[Switch]	Operating elements (e.g. push buttons, switches), display elements (e.g. LEDs)
'Display'	Screen elements (e.g. buttons or menus)

## 1.2 Correct use

The FSL-CONTROL III controller is designed exclusively for the control of TROX decentralised ventilation units.

Correct use also involves complying with all the information provided in this manual.

Any use that goes beyond the correct use or any different use of the unit is regarded as incorrect use.

## 1.3 Safety signs

The following symbols and signs are found on the unit. They apply to the very location where they are found.

### Electrical voltage



## Qualified staff

Hazardous electrical voltage that is present in the ventilation unit. Only skilled qualified electricians are allowed to work on parts of the ventilation unit marked with this symbol. Such work must be carried out only by skilled qualified electricians or the technical service.


### Controls access panel



Only skilled qualified electricians are allowed to open the controls access panel. Ensure that no voltage is present on any mains circuit before you open the cover to access the terminal connections.

## 1.4 Electric shock hazard

### Electric current

 **DANGER!**

**Danger of death due to electric current!**

Danger of electric shock! Do not touch any live components! Damaged insulation or damaged parts are a life threatening hazard.

- Only a skilled qualified electrician must work on the electrical systems.
- If the insulation is damaged, disconnect the power supply immediately and have the insulation repaired.
- Switch off the power supply before you carry out maintenance or cleaning.
- Ensure that live parts do not come into contact with moisture. Moisture can cause a short circuit.

## 1.5 Qualified staff

### Qualification

The work described in this manual has to be carried out by individuals with the qualification, training, knowledge and experience described below:

#### Network administrator

Network administrators design, install, configure and maintain the IT infrastructure in companies or organisations.

### Skilled qualified electrician

Skilled qualified electricians are individuals who have sufficient professional or technical training, knowledge and actual experience to enable them to work on electrical systems, understand any potential hazards related to the work under consideration, and recognise and avoid any risks involved.

Any work has to be carried out by individuals who can be expected to carry out their assigned duties reliably. Individuals whose reaction time is delayed due to alcohol, drugs or other medication must not carry out any work.

## 2 Making electrical connections

### DANGER!

**Electric shock hazard! Electrical equipment carries a dangerous electrical voltage!**

- Only skilled qualified electricians are allowed to work on the electrical system and to connect the unit to the mains.
- Disconnect the cable from the mains (all phases) and secure the unit against being switched on accidentally.
- Ensure that no voltage is present.
- Carry out assembly or connection jobs only as long as no voltage is present.

### Notes on the electrical installation

Use only cables that are designed for the supply voltage for which they will be used. The length and cross section as well as any contact resistance may increase voltage losses. The power rating of each unit must also be considered. A skilled qualified electrician has to select the correct cable types and sizes. This job must only be carried out by specialist electrical companies.

- For the electrical connection comply with any applicable regulations and follow the code of good practice. Be sure to comply with the applicable guidelines for working on electrical and electronic equipment as well as with any applicable local regulations.
- The connection data can be found on the rating plate or in the wiring diagrams.
- Protect any connections from physical damage.
- Feed cables through the cable glands on the ventilation unit.
- Ensure that the unit can be de-energised (all phases) for maintenance such that no voltage is present. This requires separators (e.g. fuses or RCBOs); the distance between contacts should be at least 3 mm.
- For units without integral controls from TROX follow the instructions of the controls provider.

### 2.1 Wiring

#### Personnel:

- Skilled qualified electrician
  - ▶ Connect the ventilation unit according to the wiring diagrams. The position of the electrical connections (terminal box) can be found in the device-specific documentation.

#### 2.1.1 Connection of the supply voltage




Fig. 1: Connection of the supply voltage

- 1 Connecting cable Ölflex Classic 100 3G 1.5 mm<sup>2</sup> ca. 1.0 m (supply package TROX)
- 2 Fuse 3.15 A
- 3 SCHOOLAIR-V-HV-EH only: fuse 9.0 A

### DANGER!

#### Risk to life from electrical voltage!

The control box may not be opened, it is used for the internal electrical wiring and may only be opened by TROX Service personnel.

The electrical connection is made with the connecting cable leading from the control box.

#### 2.1.2 Connection of the control panel

##### Notes on control panels

Select an installation location where the control panel is not affected by disturbances. Avoid solar gain and draughts.

Seal the end of the conduit in the junction box as otherwise a draught could occur in the conduit and affect the measurement results.

## Honeywell, 5-stage (0, 1, 2, 3, AUTO)




Fig. 2: Wiring of Honeywell control panel, 5-stage to terminal X9

- 1 Control panel with selector switch, for surface mounting, type: T7460F1000, TROX order no. M546FB8
- 2 LiYCY 5 x 0.5 mm<sup>2</sup> shielded (by others)

## Schneider, without selector switch




Fig. 3: Wiring of control panel STR 504 to terminal X9

- 1 Control panel without selector switch, for surface mounting, type: STR 504 TROX order no. M536BA4
- 2 LiYCY 5 x 0.5 mm<sup>2</sup> shielded (by others)

## Thermokon, with selector switch, 5-stage




Fig. 4: Wiring of Thermokon control panel (5-stage) to terminal X9

- 1 Control panel with selector switch, for surface mounting, type WRF04 PSTD NTC20k 5k FS5 gn 5V SA, TROX order no. A00000082515
- 2 LiYCY 5 x 0.5 mm<sup>2</sup> shielded (by others)

## Thermokon, without selector switch




Fig. 5: Wiring of Thermokon control panel to terminal X9

- 1 Control panel without selector switch for surface mounting, type WRF04 PTD NTC 20k 5k gn, TROX order no. A00000079777
- 2 LiYCY 5 x 0.5 mm<sup>2</sup> shielded (by others)



## Thermokon, without selector switch, Berker S.1 or Q.3




Fig. 6: Wiring of Thermokon control panel to terminal X9

- 1 Control panel without selector switch, for flush mounting, suitable for switch programme Berker S.1, type WRF07 PTD NTC 20k BType6 5k gn, TROX order no. A00000079778
- 1 Control panel without selector switch, for flush mounting, suitable for switch programme Berker Q.3, type WRF07 PTD NTC 20k BType6 5k gn, TROX order no. A00000081579
- 2 LiYCY 5 x 0.5 mm<sup>2</sup> shielded (by others)

## Thermokon, without selector switch, Busch Jäger Futura




Fig. 7: Wiring of Thermokon control panel to terminal X9

- 1 Control panel without selector switch, for flush mounting, suitable for switch programme Busch Jäger Futura, type WRF07 PTD NTC 20k BType6 5k gn, TROX order no. A00000079779
- 2 LiYCY 5 x 0.5 mm<sup>2</sup> shielded (by others)

## Thermokon, without selector switch, without set-point value adjuster, Gira E2




Fig. 8: Wiring of Thermokon control panel to terminal X9

- 1 Control panel without selector switch, for flush mounting, suitable for switch programme Gira E2, type WRF06 TD NTC 20k, TROX order no. A00000081503
- 2 LiYCY 5 x 0.5 mm<sup>2</sup> shielded (by others)

### 2.1.3 Connection of room temperature sensor




Fig. 9: Connection of room temperature sensor

- 1 Room temperature sensor, type RTF3-NTC10k, TROX order no. A00000059069
- 2 LiYCY 2 x 0.5 mm<sup>2</sup> shielded (by others)

## 2.1.4 Connection of external inputs and outputs

### External switch inputs




Fig. 10: Wiring example of window contact

1 Connecting cable LiYCY 2 x 0.5 mm<sup>2</sup> (by others)

### Terminal connections X3

No.	Function	Switch	
		Open	Closed
1	Fume cupboard switch	Inactive	Active
2	Changeover <sup>1</sup>	Heating	Cooling
3	Operating enable	Off	Automatic
4	Fire emergency stop <sup>1</sup>	Off	Automatic
5	Window contact <sup>1</sup>	Off	Automatic
6	PIR sensor	Valid operating mode	Occupied

<sup>1</sup> cable break safety device

### External switch outputs




Fig. 11: Wiring example B alarm

1 Connecting cable LiYCY 2 x 0.5 mm<sup>2</sup> (by others)

### Terminal connections X5

No.	Connection	Voltage / Current consumption
1	Requirements of coolant <sup>1</sup>	24 VDC, max. 250 mA
2	Requirements of heat transfer fluid <sup>1</sup>	
3	Operational readiness	
4	B alarm	
5	A alarm	
6	Enable heating ceiling	
7	Enable chilled ceiling	

<sup>1</sup> changeover mode only

2.1.5 Communication FSL-CONTROL III

2.1.5.1 Several controllers in a control zone

Up to 11 FSL-CONTROL III devices can be connected in one control zone (1 master device and up to 10 slave devices).




Fig. 12: FSL-CONTROL III communication 2 devices




Fig. 13: FSL-CONTROL III communication 3 devices

The master device must be installed on one of the two ends of the network (as the first or last device).

## Terminal resistor

For smooth data exchange between the controllers, a resistance of 120 Ohm must be set on the first and last subscriber, remove the resistances in the other devices (if available).

Installation location of terminal resistor Fig. 12 , Fig. 13

Master devices - Terminal block X2, terminals 1 and 2

Slave devices - Terminal block X1, terminals 1 and 2

## Information on network connection




Fig. 14: Wiring

All network connections via shielded cables.

**Note:** For A- and B+, use a twisted pair ①!

**Recommended network cable (by others):** e.g. Uni-tronic BUS LD 2 x 2 x 0.25 mm<sup>2</sup> or equivalent

2.1.5.2 Network with several control zones

Building a network

Control zones can be networked using one of four existing network protocols (Modbus RTU, Modbus TCP, BACnet MS/TP or BACnet IP). This requires a bus interface card to be connected to the FSL-CONTROL III master controller in the factory.




Fig. 15: FSL-CONTROL III network configuration, example Modbus RTU; BACnet MS/TP



*If the master controller is integrated in a central BMS (by others), it acts as a slave within the bus network, but as a master within the FSL-CONTROL III system.*




Fig. 16: FSL-CONTROL III network configuration, Modbus TCP; BACnet IP

## 2.2 Connection to the central building management system (central BMS)

### 2.2.1 Modbus RTU / BACnet MS/TP

#### Connection of data cables




Fig. 17: Connection of central BMS to the master device with Modbus RTU / BACnet MS/TP interface

- 1 Network cable Unitronic BUS LD 2 x 2 x 0.22 (or equivalent, by others)
  - 2 (coming) from the central building management system
  - 3 (going) to the next BUS subscriber of the central BMS
- Count up the terminal position from the grey end plate (direction of the arrow)

The Modbus RTU / BACnet MS/TP interface has terminals for max. two cables of an EIA-485 network. A maximum of 32 devices can be operated on one network segment.

#### Personnel:

- Network administrator

#### Materials:

- Software for bus communication
  - Browser
1. ▶ Strip the insulation from the cable (at least three wires), insert the bare wires into the terminals and tighten the screws by hand (only use twisted pair for B+ and A-).  
  
Make sure that the polarity of the conductor pairs is correct. Incorrect polarity will result in inverted data signals and hence communication errors.
  2. ▶ Fix the data cables to the casing using the wire clamping bracket.
  3. ▶ Connect the shield to the SH terminals.

**Note:** Within a chain (channel) connect the shield only at one point to the earth. Earthing the shield at every controller will lead to voltage disturbances.

4. ▶ To avoid cable reflections, network segments must be terminated at both ends with 120 Ω bus terminal resistors. Alternatively, the terminal resistors can be enabled or disabled on the PCB.

#### Recommended bus cables

Unitronic BUS LD 2 x 2 x 0.22 (or equivalent)

### 2.2.2 Modbus TCP / BACnet IP

#### Connection of data cables




Fig. 18: Connection of central BMS to the master device with Modbus TCP / BACnet IP interface

- 1 Network cable (coming) from the central building management system  
Network cable min. Cat 5e RJ45 (or equivalent, by others)
- 2 Terminal block X7 RJ45 interface

The devices have an RJ45 interface for star-shaped connection of devices to a Modbus TCP / BACnet IP network.

#### Personnel:

- Network administrator

#### Materials:

- Software for bus communication
  - Browser
- ▶ Insert the RJ45 connector for the cable into the intended bush (X7).

Each master must be connected with a separate cable.

#### **i** Special feature of external control box e. g. FSL-U-ZAS, FSL-U-SEK)

To simplify maintenance, connection X7 on the ventilation unit has a double construction One connection is connected to the controller box by a network cable. The second connection can be used for interfacing to the central BMS. Internally, both connections are connected, which means that communication with the BMS is guaranteed.

## Recommended bus cables

Network cable min. Cat. 5e RJ45

### 2.2.2.1 Setting the network address

#### Personnel:

- Network administrator




Fig. 19: Connect laptop to the ventilation unit

- 1 Mobile computer with Ethernet interface
- 2 Network cable min. Cat 5e RJ45
- 3 Junction box for network cable

Before operation, the interface for the devices must be adapted to the existing network structure. The configuration is carried out via the browser, .

#### Factory settings SL1 connection X1 serial bus

Address	Who	Value
16124	Address	1
16129	Baud rate X1	2
16126	Data bits X1	8
16127	Stop bits X1	1
16128	Parity X1	2

#### Master device configuration of the serial connection to the central BMS (Modbus RTU, BACnet MS/TP)

##### Address of terminal X1

This is used for the addressing of all master devices in the network. Each device is given a unique address. In a network segment, a maximum of 32 network addresses (devices) can be used. The permitted address range is 1 – 128.

For setting information, see

#### Slave device configuration for connection to the master device

##### Address of terminal X1

This is used for the addressing of the slave devices in the master / slave network. If only one slave is connected to a master device, no settings are needed. If several slave devices (max. 10 units) are connected to a master device, each slave device must be given a unique address.

Addressing example:

- Slave 1 - Value 2 Modbus address 2
- Slave 2 - Value 3 Modbus address 3
- Slave n - Value n+1 Modbus address n+1
- Slave 10 - Value 11 Modbus address 11

#### Settings X1

Address	Who	Value
16129	Baud rate ⇒ 38400 Baud	2
<b>Note:</b> No settings are needed, for communication between the master and slave, only 38400 baud is supported.		
16126	Data bits The FSL-CONTROL III controller only supports 8 data bits.	8
16127	Stop bits The FSL-CONTROL III controller only supports 1 stop bit.	1
16128	Parity ⇒ Even	2
<b>Note:</b> No settings required. Only "Even" is used for communication between master and slave.		

#### Modbus address terminal X2

The following settings are factory set and do not need to be changed.

Address	Who	Value
15774	Modbus address terminal X2	1



## 3 Control of the ventilation unit

### 3.1 FSL-CONTROL III control system

#### System overview

FSL-CONTROL III is a dedicated single room control system for decentralised TROX ventilation systems.

The FSL-CONTROL III controller can be used to combine the following concepts:

- Room temperature control using the room or extract air temperature
- Control of the supply air temperature (isothermal)
- Room air quality control (optional)

#### 3.1.1 Control components

The modular design of the hardware allows for adding optional equipment to the range of functions of the FSL-CONTROL III controller.



Fig. 20: Controller, valve with thermoelectric actuator

#### Basic equipment

- Controller for master or slave operation
- Heating and/or cooling valves, including thermoelectric actuators and lockshields; alternatively: electric reheater
- Supply air temperature sensor

#### Optional equipment

- Control panel including setpoint value adjuster and room temperature sensor
- Outdoor temperature sensor
- Air quality sensor (CO<sub>2</sub> / VOC)
- Clock and timer
- Valve actuators
- Pressure-independent control valve
- Interfaces to the central building management system
  - Modbus RTU interface
  - Modbus TCP interface
  - BACnet MS/TP interface card
  - BACnet IP interface
  - Digital switch contacts (inputs and outputs)

### 3.1.2 Functional description

#### 3.1.2.1 General

The FSL-CONTROL III controller is used to control various parameters for individual rooms.

It is primarily used to control the room temperature, i.e. to maintain the set parameters and a comfortable room climate. Alternatively, the supply air can be provided to the room with a constant temperature. With an air quality sensor (optional) it is possible to control the outdoor air flow rate based on the air quality.

#### Configuration in the web browser

*The devices are configured using the IP interface and web browser.*

#### 3.1.2.2 Room temperature control

The FSL-CONTROL III controller ensures that the comfort temperature range for each operating mode is maintained. Cascade control ensures that the comfort temperature range is quickly achieved. The supply air temperature is controlled within the set range and with internal and external loads being accounted for. This is how the comfort requirements are met.

Room temperature control requires that the following values are measured:

- Room temperature, e.g. from an optional control panel or from the central BMS
- Outdoor temperature, e.g. from the central BMS or from an optional temperature sensor in the outdoor air intake of the master unit
- Supply air temperature

#### 

*Room temperature control works best when the room temperature is measured at a carefully selected point. The control panel is ideally installed about 1.5 m above the floor. Select an installation location where the control equipment is not affected by disturbances (e.g. solar gain or draughts). We recommend adjusting the flow temperature based on the outdoor temperature in heating and in cooling mode.*

## Sample standard factory settings for room temperature control

Settings	Operating mode	
	Occupied	Unoccupied
Room temperature set-point value, heating	21.8 °C	18.0 °C
Room temperature set-point value, cooling	22.2 °C	28.0 °C
Comfort temperature range	21.8 °C to 22.2 °C	18.0 °C to 28.0 °C
Upper limit of supply air temperature (heating)	42.0 °C	42.0 °C
Lower limit of supply air temperature (cooling)	18.0 °C	13.0 °C

### Demand-based settings

These factory settings have been selected for their energy efficiency but can be changed in the web browser.

For a comfortable room climate the supply air temperature in 'Occupied' mode should be at least 18 °C. In heating mode a comfortable room climate can be achieved with supply air temperatures of up to 42 °C.

The minimum permitted supply air temperature for night ventilation is 2K under the supply air temperature threshold for unoccupied mode.

To prevent the system from constantly changing between heating and cooling mode, the room temperature is not controlled to a fixed value, but within a comfort temperature range.

When cooling, the room temperature setpoint value depends on:

- Room temperature
- Operating mode
- Temperature offset (central BMS & control panel)
- Outdoor temperature

When heating, the room temperature setpoint value depends on:

- Room temperature
- Operating mode
- Temperature offset (central BMS & control panel)
- Outdoor temperature
- Winter compensation




Fig. 21: Room temperature control

### Control response for room temperature outside the comfort temperature range:

Room temperature	Control response
Below Comfort temperature range	Heating active, the room temperature setpoint value for heating is set.
Above Comfort temperature range	Cooling active, the room temperature setpoint value for cooling is set.

If the room temperature is within the comfort temperature range, the room temperature setpoint value is set depending on the outside air temperature.

### Control response for room temperature within the comfort temperature range:

Outdoor temperature	Control response
Below Comfort temperature range	Heating active, the room temperature setpoint value for heating is set.
Above Comfort temperature range	Cooling active, the room temperature setpoint value for cooling is set.

If the outdoor temperature is also within the comfort temperature range, the room temperature setpoint value is based on the cooling and heating sequence.

If the room temperature setpoint value is changed on a control panel (e.g. by entering +2 K), both room temperature limits and hence the comfort temperature range are also changed (e.g. by +2 K) as a consequence.

If the operating mode is set to 'Occupied', the temperature control is suspended as soon as the room temperature is within the comfort temperature range.

### 3.1.2.3 Supply air temperature control

In addition to room temperature control, it is also possible to blow the supply air into the room at a constant temperature. The supply air temperature control is primarily for isothermal applications. The setpoint value for the supply air temperature is a function of the set temperature limits for heating and cooling and the current supply air temperature. If the supply air temperature is below the set lower limit, the device regulates the lower limit of the comfort band as the set supply air temperature. If the supply air temperature is above the set lower limit, the device regulates the upper limit of the comfort band as the set supply air temperature. To ensure the isothermal air supply, the same temperatures must be stored for the heating and cooling temperature limits.



**Note:**

- The heating load of the room must be covered by a separate heating source.
- The extract air temperature sensor must basically be activated.

**In addition, please note that, for devices with supply air temperature control in automatic mode, the individual fan stages are only determined on the basis of the air quality. It is therefore advisable to store a minimum fan stage for the Occupied mode. If the devices are to be ventilated during the Unoccupied operating mode, a minimum fan stage must also be stored here, but the devices ventilate exclusively in Outdoor Air mode.**

### 3.1.2.4 Constant bypass on heat recovery unit

The ventilation units that are equipped with a cross flow or cross counter flow heat recovery unit have a constant bypass (0...100%). The bypass is controlled automatically.

The bypass is used to reach the supply air temperature setpoint value in heating and cooling mode. When the "Night Purge" function is active, the bypass is open. The volume flow rate to be heated by the heat recovery unit is controlled by the bypass.

If, for example, the outdoor temperature is low, but an internal space has to be cooled anyway, use of the cooling coil can be reduced to a minimum as only a small portion or even no portion of the air has to pass the heat recovery unit.

### 3.1.2.5 Rotary heat recovery unit

In ventilation units with a rotary heat recovery unit, the rotor speed is automatically adjusted so that the supply air temperature setpoint value can be reached. During "Night purge", the rotary motion of the rotor is switched off.

Due to variable control, use of the cooling coil can be reduced to a minimum in transition times, i.e. if the outdoor temperature is low but the internal space has to be cooled anyway.

### 3.1.2.6 Fan stages

The FSL-CONTROL III controller automatically selects the correct fan stage based on temperature control or indoor air quality (optional). The fan stage can also be pre-set by the central BMS (by others) or from a control panel.




Fig. 22: Fan stages – priority

### 3.1.2.7 Air quality control (optional)

Air quality control means that the outdoor air flow rate is controlled based on the room air quality.

This type of control is only possible with an air quality sensor (optional equipment or by others). The internal sensor optionally detects the CO<sub>2</sub> concentration or the VOC content of the extract air. Air quality control is always active in the 'Occupied' operating mode. In the 'Unoccupied' operating mode, air quality control is inactive.

#### Air quality control – factory settings

CO <sub>2</sub> value [ppm]	Fan stage	
	Outdoor air	Secondary air
< 500		1-3
500 – 750	1	
750 – 900	2	
> 900	3	

The system owner can adjust the air quality values.

## **Secondary air and outdoor air modes**

*If the current measured value of the indoor air quality is under the first limit while the bypass is inactive, this means that secondary air operation is active. As soon as the configured limit of air quality for fan stage 1 is exceeded, the unit automatically switches to outdoor air mode. Preset minimum periods of time ensure that not too many quick changes between the fan stages occur.*

## **Outdoor Air mode**

*When Outdoor Air mode is activated, the ventilation unit exclusively conveys outdoor air regardless of the first limit value. The fan stages continue to be raised depending on the limit values. Outdoor Air mode can be stored as a fixed parameter, activated on the control panel (configuration of the push button) or set using the central BMS.*

### 3.1.2.8 Operating mode

The operating modes are used for higher-level control of the devices.

The following operating modes are available:

- OFF
- Automatic
- MANUAL

The above-mentioned operating modes can be set in the central BMS, on the digital control panel (CP Type01\_Digital), in the web browser and using digital switching inputs (OFF and Automatic only).

The Manual operating mode can only be activated via the web browser.

#### OFF operating mode

In the OFF operating mode, the fans are always switched off and the outdoor air and exhaust air dampers are closed. Only self-protection functions such as frost protection are still active.

OFF can be used as an operating enable if a device is to be controlled independently of the operation on the control panel, as well as independently of the internal clock.

## **Recommended**

*OFF serves exclusively the self-protection of the device and can be selected for longer standstill periods, such as holidays. In particular, the protection of the building protection must be safeguarded by other heat sources.*

#### Automatic operating mode

The Automatic operating mode is the standard operating mode for ventilation units.

The control of the ventilation unit can be influenced by the following signal transmitters:

- Central BMS
- Real time clock (RTC)
- Control panel
- Digital input

#### Manual operating mode

The Manual operating mode is used for commissioning or equipment maintenance.

It can only be activated on the device itself by accessing the web server.

In the Manual operating mode, individual actuators can be controlled manually, e.g. valves for hydraulic balancing.

### 3.1.2.9 Operating modes / operating mode override

Automatic operating modes:

- Standby
- Occupied
- Unoccupied

Operating mode override:

- Boost
- Exercise
- Night purge
- Fan force



*With an operating mode override, the current automatic operating mode is overridden. Once this override has been completed, the device returns to automatic mode.*

The specified operating modes and overrides can be set using the optional real-time clock and the central BMS. In addition, the Occupied and Unoccupied operating modes as well as the Boost and Exercise overrides can be activated from the control panel.

Various comfort temperature ranges can be defined for the operating modes Occupied and Unoccupied. You can define daily schedules and enter a start time for each operating mode. Using the optional real time clock (RTC) allows for defining 10 switching points per day. If no RTC is used, operating modes must be changed by the central BMS or on the control panel. The comfort temperature range for the Occupied mode can be modified on the control panel and by the central BMS.

### Standby operating mode

Standby is selected if the room is not occupied and the ventilation units are not used to maintain the temperature, e.g. at night.

#### **Recommended:**

*Standby is used exclusively for the self-protection of the device and should only be selected if the protection of the building protection is safeguarded by other heat sources.*

### Occupied operating mode

The Occupied mode is used for occupied rooms.

The following parameters can be set:

- Comfort temperature range for Occupied
- Supply air temperature limits for heating/cooling

#### **Recommended**

*All-day use (e.g. 7 am to 5 pm)*

### Unoccupied operating mode

The Unoccupied mode is used for unoccupied rooms.

The following parameters can be set:

- Comfort temperature range for Unoccupied
- Supply air temperature limits for heating/cooling

#### **Unoccupied**

- *This operating mode is used to protect the building; it is required for night purge.*
- *Air quality control is not possible with this operating mode.*

### Boost operating mode override

Boost can be selected to quickly ventilate a room, e.g. during break times. The device ensures supply air/extract air operation to improve the indoor air quality. Afterwards, the device returns to the Occupied operating mode.

The following parameters can be set:

- Fan setting (default: stage 4)
- Duration (default: 15 min.)

#### **Boost**

*Boost mode can be enabled using the control panel or central BMS. The same setpoint values that are used for Occupied mode are used for the comfort temperature range and supply air temperature limits.*

### Exercise operating mode override

Exercise can be selected if acoustically optimised operation is required. The device conveys a slightly reduced volume flow rate in supply air/extract air operation to improve the indoor air quality. Afterwards, the device returns to the Occupied operating mode.

The following parameters can be set:

- Fan setting (default: stage 2)
- Duration (default: 60 min.)

#### **Exercise**

*Exercise mode can be enabled using the control panel or the central BMS. The same setpoint values that are used for Occupied mode are used for the comfort temperature range and supply air temperature limits.*

### Night purge operating mode override

With the Night purge function, the room is passively cooled with outdoor air. The minimum supply air temperature corresponds to the supply air temperature limit for heating in Unoccupied mode of -2K. The fans are controlled in the configured stage for night ventilation. The max. fan stage for Unoccupied operating mode is ignored for the duration of night ventilation.

The following conditions must be simultaneously fulfilled:

- Night purge is activated
- The current month is in the range Start – End – Month (default: May – September)
- Activated by RTC, central BMS or DI
- Outdoor air temperature > minimum outdoor air temperature for Night purge (default = 12 °C)
- Outdoor air temperature < as a setpoint value for cooling in the Occupied operating mode
- Outdoor air temperature < current room temperature
- Supply air temperature > minimum supply air temperature limit for heating in the Unoccupied operating mode

The Night purge function ends when one of the following conditions are fulfilled:

- Frost protection
- Window contact
- Fire protection
- Fan force

- Switch of operating mode to Standby or Occupied
- Switch of operating mode to Off or Manual

**Note**

When the Night purge operating mode override ends, the device switches to Unoccupied. Secondary air units do not execute this override.

**Fan force override (fume cupboard switching)**

With the Fan force function, there is an override of the fans via the DI, RTC or central BMS. For the duration of the activation, the fans are operated separately from one another in a configurable stage for supply air and extract air.

**Fume cupboards**

Fume cupboards, e.g. in seminar rooms, can dissipate high volume flow rates. Override control can help to achieve balanced volume flow rates.

The volume flow rates of fume cupboards must be specified when planning devices.

When Fan force is active, the Occupancy button and the default fan setting are deactivated on the control panel.




Fig. 23: Sample configuration of winter compensation

- 1 Room temperature setpoint value
- 2 Outdoor temperature
- 3 Comfort temperature range without winter compensation
- 4 Comfort temperature range with winter compensation
- 5 Max. increase in setpoint value  
Default temperature for winter compensation start  
Maximum winter compensation

**Recommended**

Winter compensation active

**3.1.2.10 Functions**

The following functions of control are factory set on the basis of customer-specific requirements. TROX HGI Service can change the factory settings at a later stage.

**3.1.2.10.1 Winter compensation**

Winter compensation is the automatic adjustment of the comfort temperature range depending on the outdoor air temperature.

**3.1.2.10.2 Minimum fan stages**

The minimum ventilation stage function enables forced ventilation in the various operating modes. There is a choice between fan stages 0-5 for operation of the device in the respective operating mode.

**Recommended**

- Occupied – fan stage 1
- Unoccupied – fan stage 0

**3.1.2.10.3 Secondary air function**

If the indoor air quality is good, the controller switches to secondary air mode, which is more energy efficient. The shut-off dampers are closed and the supply air fan remains switched on.

The controller compares the indoor air quality limit value to the ACTUAL values measured by the air quality sensor and switches automatically between outdoor air and secondary air mode.

Secondary air changeover is an option and only possible with air quality measurement (integral function or as a data point of the central BMS).

The secondary air function is not available for all unit variants.



#### **Recommended**

*Limit value: 500 ppm*

#### **3.1.2.10.4 Frost protection**

The FSL-CONTROL III controller has frost protection functions to protect the building and device. When the temperature of the outdoor air, supply air or room is too low, frost protection is implemented.

The device carries out the following actions:

- Operating mode = Automatic
- Operating mode = Standby
- Outdoor air and exhaust air dampers closed
- Fan(s) switched off
- Heating valve 100% open

#### **Room temperature frost protection**

Devices with room temperature control have the room temperature frost protection function. Room temperature frost protection is dependent on the room temperature that is either measured by the control panel or by the central BMS as a data point. When the room temperature (central BMS) or measured room temperatures are below a pre-set limit (default = 8 °C), the frost protection function is activated and the actions described above are executed. The device will only return to its original configuration after a configured waiting period (default = 360 s) and when a room temperature of at least 1 K (configurable) over the room temperature frost limit is reached.



#### **Recommended**

*Room temperature limit: 8 °C*

*For connection to the central BMS: ensure transmission of data points!*

#### **Supply air temperature frost protection**

To prevent the heat exchanger from freezing and becoming damaged as a consequence, the supply air temperature is measured immediately after the heat exchanger. When the pre-set limit for the supply air temperature Frost 1 (default = 12 °C) is not reached, the Frost 1 supply air temperature alarm is activated. Other actions are not executed at this temperature. If the temperature does not reach the pre-set Frost 2 supply air temperature limit (default = 8 °C), the frost protection function is activated and the actions described above

are executed. The device will only return to its original configuration after a configured waiting period (default = 360 s) and when the supply air temperature goes above the supply air temperature Frost 2 limit, with a minimum difference of 1 K (configurable).



#### **Recommended**

*Frost 1 supply air temperature limit: 12 °C*

*Frost 2 supply air temperature limit: 8 °C*

#### **Frost protection**

If the outdoor temperature is  $\leq -20$  °C (can be configured), the ventilation unit is switched off to protect the device components when operating temperatures are too low.



#### **Recommended**

*Limit value: -20 °C*

#### **Heat recovery frost protection**

When outdoor air temperatures are low (default = -6 °C depending on the heat recovery unit used), there is the risk that the heat recovery unit will no longer provide ventilation or provide insufficient ventilation on the extract air side due to condensate.

The controller opens the motorised bypass damper to completely bypass the heat recovery. The bypass remains open until the outdoor air temperature has risen to at least 1 K (can be configured) above the limit.



#### **Recommendation depending on the type of heat recovery unit**

*Cross flow: -6 °C*

*Cross counterflow: -4 °C*



#### **Heat recovery all year round**

*In devices with a condensate drain, the heat recovery unit can also be operated when outdoor air temperatures are low. Here, there is a regular switch between supply/extract air operation and secondary air operation. During secondary air operation, ice that has formed could melt and drain off. The device then returns to supply air and extract air operation. A drain for condensate is therefore essential.*

### 3.1.2.10.5 Priming (start-up delay in winter)

To prevent frost damage to heat exchangers after a device restart, ending of the frost protection function or a switch of fan stage from 0 to 1 in supply/extract air operation, the ventilation unit has a start-up delay in winter function. With this function, the device primes during the winter months (November to March, configurable) or when outdoor air temperatures are under 3 °C (configurable) with the heating coil switched on.

The start-up delay in winter is executed before commissioning of the fans when one of the following conditions are fulfilled:

- Current month is between November and March
- Outdoor air temperature < limit (default = 3 °C)

To heat the heating coil, the heating coil is 100% opened for 300 seconds (configurable). Ventilation units with constant bypass close the bypass, devices with rotary heat recovery units switch on the rotor. Once the pre-heating time has ended, the heating valve is limited for 45 seconds to 60% (configurable). The device then returns to the specified operating mode.




Fig. 24: Diagram of heating valve control signal

- 1 Control signal
- 2 Time
- 3 Control system
- 4 Limitation
- 5 Priming
- 6 Standby

#### Recommended

- Limit temperature for outdoor air: 3 °C (all year)
- Duration of priming: 300 seconds
- Duration of limitation: 45 seconds
- Valve setting limitation: 60%

### 3.1.2.10.6 Night ventilation

With the Night purge function, the building can be cooled at night during the summer as long as the outdoor air offers sufficient cooling potential.

The following requirements must be fulfilled:

- Night purge is configured in the device
- Current month is in the start-end-month range for Night purge
- Activated by RTC, central BMS or DI
- Outdoor air temperature < setpoint value for cooling for Occupied mode (difference can be configured)
- Outdoor air temperature < room temperature (difference can be configured)
- Outdoor air temperature > minimum outdoor air temperature for Night purge (default = 8 °C, configurable) supply air temperature > minimum supply air temperature - heating limit in Unoccupied mode -2K

#### ENVIRONMENT!

##### Saving energy

Night purge provides a high energy savings potential as rooms can be 'pre-cooled' at night without using a cooling coil.

#### Recommended

- Highest fan stage
- Start month: May
- End month: October

### 3.1.2.10.7 Filter change alert

The 'Monitoring filter replacement interval' function (i.e. filter change alert) alerts users in each of the following cases that a filter change is due:

- The number of operating hours exceeds the preset value (factory set to 2500 h, adjustable)
- The differential pressure at the outdoor air filter exceeds the preset value (only for unit variants \*-HE and \*-HV)

The need for a filter change is signalled by a double flashing of the LED on the control panel or in the web browser via "Operating hours of remaining filter time" (11251)

When connected to the central BMS, the filter change is output as a B alarm.

#### Note

If the permitted differential pressure on the outdoor air filter is exceeded, the "Operating hours of remaining filter time" (11251) is reset to 0 h in the software.



### Differential pressure monitoring

The ventilation units (master only) variants \*-HE and \*-HV come with a differential pressure monitoring function. This function monitors the differential pressure of the outdoor air filter up to the nominal air volume (usually stage 3) If the differential pressure exceeds the preset value for at least 30 minutes, the filter change alert is activated (see above). In the Boost, Fan Force and Night Purge operating mode overrides, the differential pressure monitoring function is inactive to prevent unnecessary filter changes.

#### Filter checks

*Differential pressure monitoring is not supposed to replace any regular checks of the outdoor air filter or checks due to hygiene reasons.*

### Resetting the filter change alert

The filter change interval has to be reset after each filter change using one of the following methods:

- On the analogue control panel -> press and hold the Occupied button (for 15 - 20 sec.)
- In the web browser 'menu' → Reset filter hours, address 10006'
- Central BMS by others

#### 3.1.2.10.8 Fan force

↪ 'Fan force override (fume cupboard switching)' on page 22

#### 3.1.2.11 Interfaces

Master devices have 6 digital inputs and 7 digital outputs. All contacts can be configured as NO or NC contacts. You can use these for the following functions, for example:

- Digital inputs
  - **Window contact:** As soon as a monitored window is opened, the master and slave devices in the room are switched off (default: normally open).
  - **Changeover function:** Allows for changing from heating to cooling and vice versa in 2-pipe-heat exchangers (default: NC contact).  
**Logic:**  
Open = Heat transfer fluid present  
Closed = Coolant present
  - **Fire emergency stop:** Master and slave devices are switched off if a signal is received at the corresponding input (default: normally open).
  - **PIR:** Manual activation of Occupied operating mode (default: NO contact) e.g. by a PIR sensor.  
**Logic:**  
Open = Device in valid operating mode  
Closed = Device in Occupied

- **Fume cupboard switching:** Manual activation of Fan Force (default: NO contact).
- **Enable:** Enable operation of the device. If there is no Enable, the device cannot be put into operation (higher-level OFF)

#### Digital inputs

*Wiring of digital inputs with 24 VDC 2.5 mA for connecting volt-free contacts.*

- Digital outputs
  - **A alarm**
  - **B Alarm**
  - **Secondary cooling system:** enable for chilled ceiling
  - **Secondary heating system:** enable for heating system
  - **Operational (standby) message**
  - **Heat transfer fluid requirements:** for changeover mode
  - **Coolant requirements:** for changeover mode

#### Digital outputs:

*Permitted load of digital outputs: 24 VDC / 250 mA.*



## 4 Description of software

To set up the FSL-CONTROL III controller, a PC can be connected to the ventilation unit using the IP interface. Typically, the ventilation units are integrated into the building network via the BUS interface during installation. The devices can then be reached by the central BMS computer.

The control parameters are set and configured in the web browser. The web browser is also used for maintenance work.

To connect a PC to the FSL-CONTROL III controller, a patch cable is needed.




Fig. 25: Patch cable min. Cat. 5 S/FTP RJ45



### **Standard network address**

To call up the software to the address line of the browser, enter the IP address of the FSL-CONTROL III controller.

*Factory settings:*

- IP address master: 10.2.100.242
- IP address slave: 10.2.100.243
- User name: TROX
- Password: FSL
- IP gateway: 10.2.20.1
- Subnet mask: 255.255.255.0

The FSL-CONTROL III controller does not have a DHCP, if necessary change the DHCP settings of the Ethernet connection.

## 4.1 Start screen – Diagnostics

Diagnose
Konfiguration
Hand Steuerung
Verbindung GLT

① Diagnose > Gerätestatus

### Gerätestatus

Adresse	Bezeichnung	Wert
13000	Gerätestatus: Grün=Regelung Grau=Regelung+Übersteuerung Rot=keine Regelung	<span style="color: green; font-size: 2em;">●</span>

③ Geräteinformationen

Adresse	Bezeichnung	Wert
11055	FSL-CONTROL III Gerätetyp: 1-Sek 2-ZuSek 3-Zus 4-ZabSek 5-Zas	4
11009	Gerätebezeichnung	SCHOOLAIR
11000	Seriennummer	DE12345678123123
11056	Master/Slave Gerät: 0-Slave 1-Master	1
11036	Softwareversion	FSL-CONTROL III
11045	Softwareversion	6.4

④ Betriebsinformationen

Adresse	Bezeichnung	Wert
11057	Betriebsmodus: 1-Aus 2-Automatik 3-Hand	2
11058	Betriebsart: 0-Ohne 1-Standby 2-Abwesend 3-Anwesend	3
11059	Betriebsartübersteuerung: 0-Ohne 1-Boost 2-Klausur 3-Nachlüften 4-Lüfterzwangsbeschaltung	0
11060	Betriebsstatus: 0-Ohne 1-Standby 2-Regelung 3-Hand 6-Brand 7-Frost 8-Vorspülen 11-Nachlüften	2
11061	Quelle der Betriebsart: 1-RBG 2-GLT 3-RTC 4-DI 5-Master 6-PC	3
11131	Frostschutz ausgelöst: 0-Kein Frostschutz 1-Frostschutz	0

⑤ Lüftungsinformationen

Adresse	Bezeichnung	Wert
11078	Lüfterstufe Zuluft	3
11077	Lüfterstufe Abluft	3
11092	Lüftungsart: 0-Aus 1-Sekundärluftbetrieb 2-Außenluftbetrieb	2
11121	RBG - Lüfterstufe: 255=Ohne 0=0 1=1 2=2 3=3 10=Auto	10

⑥ Systeminformationen

Adresse	Bezeichnung	Wert
11120	Anzahl aktiver Geräte im System	1
9271	Kommunikationszähler Master <-> Slave	21828

⑦ Betriebsstunden

Adresse	Bezeichnung	Wert
11085	Betriebsstunden Lüfter Zuluft	0
11083	Betriebsstunden Lüfter Abluft	0
11087	Betriebsstunden Lüfter Sekundärluft	0
11089	Betriebsstunden Filter	2500
11252	Betriebsstunden Filterrestlaufzeit	0
11062	Betriebsstunden Gerät	506
11249	Betriebsstunden seit letztem Neustart des Gerätes	0

⑧ Reglerinformationen

Adresse	Bezeichnung	Wert
13004	SD Karte aktiv 0-Deaktiviert 1-Aktiviert	1
13003	Firmware Version	596
13002	Firmware Revision	9
13005	Regler Type 2051=42-IO 2049=28-IO	2051

Fig. 26: Start screen for web browser FSL-CONTROL III

- |   |   |
|---|---|
| <p>① Main menu, Diagnostics, Configuration, Manual (Control), (Connection to) Central BMS</p> <p>② Display of device status in traffic light form</p> <p>③ Display of device information</p> <p>④ Display of operating information</p> <p>⑤ Display of ventilation information</p> <p>⑥ Display of system information</p> | <p>⑦ Display of operating hours</p> <p>⑧ Display of controller information</p> <p>A Modbus register</p> <p>B Description</p> <p>C Value / condition</p> |
|---|---|

**Main menu structure**

Diagnosis	Configuration	Manual	Connection to central BMS
<ul style="list-style-type: none"> <li>■ Device status</li> <li>■ Temperature control</li> <li>■ Fan control</li> <li>■ Alarms and filter reset</li> </ul>	<ul style="list-style-type: none"> <li>■ Device description</li> <li>■ Temperature control</li> <li>■ Clock and timer</li> <li>■ Fan control</li> <li>■ Interfaces</li> </ul>	<ul style="list-style-type: none"> <li>■ Commands</li> </ul>	<ul style="list-style-type: none"> <li>■ Device =&gt; central BMS</li> <li>■ Central BMS =&gt; device</li> </ul>

Menu items with \*+ are protected with a password and are only available to TROX Service.

**4.2 Diagnostics menu**

**4.2.1 'Device status → diagnostics'**

**Device status**

Address	Who	Value	Explanation
13000	Device status	● Green	<ul style="list-style-type: none"> <li>■ Automatic mode</li> <li>■ Device OK</li> </ul>
		● Grey	<ul style="list-style-type: none"> <li>■ Override active</li> <li>■ Device OK</li> </ul>
		● Red	Device inactive (e.g. as a result of frost protection)

**Device information**

Address	Who
11055	<b>Display of device type</b> 1 = Secondary air unit 2 = Supply and secondary air unit with option of changeover to secondary air 3 = Supply air and secondary air unit 4 = Supply air and extract air unit with heat recovery and option of changeover to secondary air 5 = Supply air and extract air unit with heat recovery and secondary air mixture
11009	<b>Device description</b> Individual device description
11000	<b>Serial number</b> Serial number of the device
11056	<b>Master / slave</b> 0 = Slave device 1 = Master device
11036	<b>Software name</b> FSL-CONTROL III
11045	<b>Software version</b> Display of software version

**Operating information**

Address	Explanation
11057	<b>Operating mode</b> 1 = Off 2 = Automatic 3 = Manual mode
11058	<b>Operating mode</b> 0 = No default 1 = Standby 2 = Unoccupied 3 = Occupied
11059	<b>Operating mode override</b> 0 = No override active 1 = Boost activated 2 = Exercise activated 3 = Night purge activated 4 = Fan force activated
11060	<b>Operating state</b> 0 = None 1 = Standby 2 = Control system 3 = Manual mode 6 = Fire emergency stop 7 = Frost alarm 8 = Priming 11 = Night purge

Address	Explanation
11061	<b>Setting of operating mode by...</b> 1 = Control panel 2 = Central BMS 3 = Real time clock 4 = Digital input 5 = Master 6 = PC
11131	<b>Frost protection</b> 0 = Frost protection inactive 1 = Frost protection active

## Ventilation information

Address	Explanation
11078	<b>Supply air fan stage</b> Setting of active fan stage for supply air fan.
11077	<b>Extract air fan stage</b> Setting of active fan stage for extract air fan
11092	<b>Type of ventilation</b> 0 = No ventilation 1 = Secondary air operation 2 = Outdoor air operation
11121	<b>Specification of the fan stages for TROX control panels</b> 255 = None (control panel without stage selector) 1 = 0 2 = 1 3 = 2 4 = 3 10 = Automatic

## System information

Address	Explanation
11120	<b>Number of active devices in the system</b> Display of recognised master-slave devices in the TROX network
9271	<b>Communication counter master–slave</b> Used for monitoring communication between the master device and the connected slave devices

## Operating information

Address	Explanation
11085	<b>Operating hours of supply air fan</b> Display of operating hours of supply air fan

Address	Explanation
11083	<b>Operating hours of extract air fan</b> Display of operating hours of extract air fan.
11087	<b>Operating hours of secondary air fan</b> Display of operating hours of secondary air fan (if available)
11089	<b>Operating hours of filter</b> Display of operating hours of outdoor air filter.
11062	<b>Operating hours of device</b> Display of total operating hours of the ventilation unit.
11248	<b>Operating hours since the device was last restarted</b> Display of operating hours since the device was last restarted.

## Controller information

Address	Explanation
13004	<b>SD card</b> 0 = SD card inactive 1 = SD card active
13003	<b>Firmware version</b> Output of the current controller firmware
13002	<b>Firmware revision</b> Output of the current controller revision
13005	<b>Controller type</b> Output of the controller type

## 4.2.2 'Temperature control → diagnostics'

### Temperature control

Address	Explanation
17305	Output of the configured control strategy 0 = Supply air temperature control (an extract air temperature sensor must be configured for supply air temperature control). 1 = Room temperature control 2 = Extract air temperature control
11104	Output of the current control sequence 1 = Cooling 2 = Cooling with heat recovery 3 = Heating with heat recovery 4 = Heating
11133	Output of current outdoor air temperature

Address	Explanation
11138	Output of current flow temperature
11137	Output of current return temperature
11124	Output of the temperature offset configured on the control panel



#### Temperature sensor

If there is no measured value, e.g. no temperature sensor, the value 32767 is output.

#### Room / supply air temperatures

Address	Who
11095	Upper temperature limit for cooling, comfort temperature range [1/10 °C]*
11096	Lower temperature limit for heating, comfort temperature range [1/10 °C]*
11134	Room temperature actual value [1/10 °C]
11093	Room temperature setpoint value [1/10 °C].
11132	Supply air temperature actual value [1/10 °C]
11097	Supply air temperature setpoint value [1/10°C]

\* An upper and lower temperature limit is usually set for Occupied and Unoccupied.  
For room temperature control to an absolute value, the setpoint value is displayed here.  
For supply air temperature control, the setpoint value is displayed here.

#### Control variables

Address	Who
11140	Actual value of heating valve control [1/10%] *
11141	Actual value of cooling valve control [1/10%] *
11145	Actual value of bypass damper control [1/10%] Bypass or RWT [1/10%] heat recovery*

\*Display depends on the device equipment

#### 4.2.3 'Fan control → diagnostics'

##### Type of ventilation

Address	Who
11092	<b>Type of ventilation:</b> 0 = No ventilation 1 = Secondary air operation 2 = Outdoor air operation
111989	<b>Outdoor air dampers position</b> 0 = Closed 1 = Open
11254	Outdoor air automatic 0 = Disabled 1 = Enabled
11078	Output of calculated fan stage supply air
11077	Output of calculated fan stage extract air
11079	Output of calculated fan stage secondary air
11081	Output of supply air fan speed [rpm]
11080	Output of extract air fan speed [rpm]

##### Fan stages

Address	Who
11106	Fan stage off temperature control
11107	Fan stage off air humidity control
11111	Fan stage off air quality control

##### Humidity/air quality measured values

Address	Who
11110	Room air humidity [%]
11113	Indoor air quality [ppm]

## 4.2.4 'Alarms and filter reset' → diagnostics'

### Reset filter hours

Address	Who
10006	Reset filter hours: 0 = No default 1 = Reset

### A alarm standby

Address	Who
11252	A alarm fan block – device in standby 0 = Inactive 1 = Active

### A alarm

Category A alarms can sometimes result in devices being switched off.

The alarm is always output in the form of a consolidated alarm (address 11160) and individually (address 11146 – 11159).

In the case of the consolidated alarm (address 11160), this is a 16-digit bit string made up of all category A alarms. It is output as a decimal number that must be converted to the binary number system. The following alarms are shown depending on the bit used:

- Bit 0 = Master – slave version conflict
- Bit 1 = No communication with expansion module
- Bit 2 = Missing communication CP Type01\_Digital
- Bit 3 = Currently not in use
- Bit 4 = Group alarm of connected slave devices when there is an A alarm
- Bit 5 = Supply air fan blockage
- Bit 6 = Extract air fan blockage
- Bit 7 = Currently not in use
- Bit 8 = Currently not in use
- Bit 9 = Supply air temperature sensor measured value outside tolerance
- Bit 10 = Fire emergency stop
- Bit 11 = Indoor air temperature sensor measured value outside tolerance
- Bit 12 = Mixed flow air distribution temperature sensor measured value outside tolerance
- Bit 13 = Outdoor air temperature sensor measured value outside tolerance
- Bit 14 = Currently not in use
- Bit 15 = Currently not in use

#### Examples:

1) **Address 11160** ⇒ 32 (decimal) ⇒ 0000000000010000 (binary)

Bit 5 = 1 ⇒ Supply air fan blockage

2) **Address 11160** ⇒ 8224 (decimal) ⇒ 000010000010000 (binary)

Bit 5 = 1 ⇒ Supply air fan blockage

Bit 11 = 1 ⇒ Indoor air temperature sensor measured value outside tolerance

The alarms of category A are individually listed below.

Alarm status of the respective alarms

Value 0 - No alarm

Value 1 - Alarm present

### A alarm

Address	Who
11160	Alarm A consolidated alarm, see above for description
11146	Master – slave version conflict
11147	No communication with expansion module
11148	Missing communication CP Type01_Digital
11149	Not used
11150	Group alarm A alarms slaves (A1, A2, A3, etc.) > 0)
11151	Supply air fan blockage
11152	Extract air fan blockage
11153	Not used
11154	Not used
11156	Fire protection
11155	Supply air temperature sensor measured value outside tolerance
11157	Indoor air temperature sensor measured value outside tolerance
11158	Mixed air temperature sensor measured value outside tolerance
11159	Outdoor air temperature sensor measured value outside tolerance

### B Alarm

If there is an alarm in category B, an alert is issued. The devices continue to run in the current operating mode.

The alarm is always output in the form of a consolidated alarm (address 11173) and individually (address 11161 – 11171). 11173 consolidated alarm.

In the case of the consolidated alarm (address 11173), This is a 16-digit bit string made up of all category B alarms. It is output as a decimal number that must be converted to the binary number system. The following alarms are shown depending on the bit used:

Bit 0 = No heat transfer fluid / coolant

Bit 1 = Filter change / filter pressure monitoring triggered



- Bit 2 = Frost return temperature
- Bit 3 = Frost outdoor air temperature
- Bit 4 = Frost indoor / extract air temperature
- Bit 5 = Frost 1 supply air temperature (< 12°C)
- Bit 6 = Frost 2 supply air temperature (< 8°C)
- Bit 7 = Extract air temperature sensor measured value outside tolerance
- Bit 8 = Return air temperature sensor measured value outside tolerance
- Bit 9 = Flow temperature sensor measured value outside tolerance
- Bit 10 = Humidity sensor measured value outside tolerance
- Bit 11 = Air quality sensor measured value outside tolerance
- Bit 12 = Currently not in use
- Bit 13 = Currently not in use
- Bit 14 = Currently not in use
- Bit 15 = Currently not in use

**Examples**

- 1) **Address 11173** ⇒ 32 (decimal) ⇒ 0000000000010000 (binary)  
 Bit 5 = 1 ⇒ Frost 1 supply air temperature
- 2) **Address 11173** ⇒ 8224 (decimal) ⇒ 000010000010000 (binary)  
 Bit 5 = 1 ⇒ Frost 1 supply air temperature  
 Bit 11 = 1 ⇒ Air quality sensor measured value outside tolerance

**B Alarm**

Address	Who
11173	Alarm B consolidated alarm
11161	No heat transfer fluid / coolant
11162	Filter change reached or pressure monitoring triggered
11163	Frost return temperature
11164	Frost outdoor temperature
11165	Frost indoor / extract air temperature
11166	Frost supply air temperature 1 (limit 12°C)
11167	Frost supply air temperature 2 (limit 8°C)
11168	Extract air temperature sensor measured value outside tolerance
11169	Return air temperature sensor measured value outside tolerance
11170	Flow temperature sensor measured value outside tolerance
11172	Humidity sensor measured value outside tolerance

Address	Who
11171	Air quality sensor measured value outside tolerance

**4.2.5 'Diagnostics → Remaining run times\*+'**

This page provides an overview of all running timers.

**Reset times**

In this way, all timers can be reset to "0". If the device is in frost protection mode, for example, because the outdoor temperature was missing and this temperature is now present, the waiting time can be shortened. Use only for commissioning!

**Operating mode overrides**

Address	Who
11227	Display of the remaining time in the Boost operating mode override
11228	Display of the remaining time in the Exercise operating mode override
11229	Display of the remaining time after activation of overtime
11230	Display of the minimum run time in the Night Purge operating mode override

**Fan**

Address	Who
11231	Display of remaining running time when switching from SEK to AUL or AUL to SEK
11233	Display of the start-up delay of the supply air fan when the shut-off dampers open and the fan was previously switched off.
11234	Display of the start-up delay of the extract air fan when the shut-off dampers open and the fan was previously switched off.
11232	Display of the remaining run time when switching the fan stages.

**Frost mode**

Address	Who
11235	Display until the renewed check as to whether the supply air temperature is still < 12°C.
11236	Display until the renewed check as to whether the supply air temperature is still < 8°C.

Address	Who
11237	Display until the renewed check as to whether the condition for room temperature frost (default: 8°C) is still present.  Room temperature frost is also displayed if there is no information about the extract air temperature even though the value is required (supply air or extract air temperature control is active).
11238	Display until the renewed check as to whether the condition for outdoor temperature frost (default: -20°C) is still present.
11238	Display until the renewed check as to whether the condition for outdoor temperature frost (default: -20°C) is still present.
11239	Display until the renewed check as to whether the condition for return temperature frost (default: 8°C) is still present. Currently in use.
11240	Display until the renewed check as to whether the condition for HRU temperature frost is still present. Different temperatures are stored for the different heat recovery units:  <b>Cross-flow HRU:</b> -6°C (If the outdoor temperature is lower than -6°C, the bypass is switched or, if active, the secondary air cycle is executed).  <b>Cross-counterflow:</b> -4°C (If the outdoor temperature is lower than -6°C, the bypass is switched or, if active, the secondary air cycle is executed).  <b>Rotary HRU:</b> -20 °C (This switches off the HRU temperature frost, as rotors cannot ice up).
11241	Display of run time in outdoor air mode with the secondary air cycle activated
11242	Display of run time in secondary air mode with the secondary air cycle activated
11244	Display of the remaining duration of the pre-purge process

## Filter

Address	Who
11243	Display of the minimum duration until the filter change is displayed for filter pressure monitoring. Filter pressure monitoring is only active on the master units of the *-HE and *-HV variants.

## 4.2.6 'Diagnostics → IO connections\*+'

This page gives an overview of the status of all analogue and digital inputs and outputs.

For all non-configured inputs and outputs, "0" or "32767" is displayed.

The designations refer to the standard wiring of the unit type ZAB.

The wiring of the ZAS devices deviates from this standard wiring; in this case, please always check the wiring diagrams.

## AO

Address	Who
11175	Heating valve control signal
11176	Bypass damper control signal / rotary heat recovery unit
11177	Supply air fan control signal
11178	Extract air fan control signal
11179	Control input signal of LED control panel
11180	Cooling valve control signal
11181	Secondary air damper/fan control signal
11182	Free

## AI

Address	Who
11185	Actual supply air temperature
11186	Current outdoor air temperature
11187	Current air quality
11188	Current humidity
11189	Current resistance setpoint value adjuster
11190	Current resistance button (only CP Type02) If CP Type03 is configured, then '32767' At the press of the button = '0'
11191	Current room air temperature
11192	Current extract air temperature (temperature sensor = NTC10k)
11193	Current return temperature
11194	Current flow temperature
11195	Current flow sensor measured value
11196	Current extract air temperature (temperature sensor = 0...10 VDC)

**DO**

Address	Who
11199	Condition of the shut-off dampers
11200	A alarm output
11201	B alarm output
11202	"In operation" signal output 1 = Occupied / Unoccupied 0 = Standby
11203	Reheater enable (currently not in use)
11204	Heat transfer fluid request Use only in case of changeover!
11205	Coolant request Use only in case of changeover!
11206	Humidification request (currently not in use)
11207	Preheater enable (currently not in use)
11208	Heating ceiling enable (room related!)
11209	Chilled ceiling enable (room related!)

**DI**

The wiring status is basically displayed here.  
1 = Wired  
0 = Not wired

Address	Who
11211	Supply air fan speed signal
11212	Extract air fan speed signal
11213	Secondary air speed signal For ZAS devices with a separate SEK fan, the speed signal is not detected. For SEK devices, the speed signal is output as a supply air fan speed signal.
11214	Presence switch 1 = Occupied (override of RTC, CP, central BMS) 0 = Occupied / Unoccupied control via CP, RTC or central BMS
11215	Window contact 1 = Contact closed, device functioning 0 = Contact open, operating mode = OFF
11216	Fire protection 1 = Contact closed, device functioning 0 = Contact open, operating mode = OFF, operating status = fire
11217	Release 1 = Contact closed, device functioning 0 = Contact open, operating mode = OFF

Address	Who
11218	Changeover 1 = Cooling 0 = Heating
11219	Frost protection sensor Not supported.
11220	Filter monitoring 1 = Triggered (time and/or pressure) 0 = Not triggered
11221	Night purge Not supported.
11222	Fume cupboard switch 1 = Fan force active 0 = Fan force inactive  Note: The fan force function must be activated via fan control*+, address 17472.

**4.2.7 'Diagnostics  
→ Secondary air addition\*+'**

**Mixed air temperature control**

Address	Who
11136	Current mixed air temperature Output when mixed air temperature sensor is configured.
11098	Setpoint value of mixed air temperature 0 = No mixed air temperature control active
11144	Output signal for SEK damper 0 = No mixed air temperature control active
11091	Increase of the control voltage for ZUL-Vent with SEK addition if condensate prevention is active.

**Ventilation**

Address	Who
11092	Type of ventilation 0 = Off 1 = Secondary air operation 2 = Outdoor air operation
11078	Calculated fan stage ZUL, depending on temperature and air quality
11077	Calculated fan stage ABL, depending on temperature and air quality
11078	Calculated fan stage SEK, depending on temperature and air quality

## Measured values for condensate prevention

Address	Who
11110	Humidity (measured at the ABL)
11135	Current extract air temperature (measured at the humidity + temperature combination sensor)

## Help information for fan control

Address	Who
11251	Fan control To check which control function is currently being performed. A flow chart is required for interpretation!

## 4.3 Configuration menu

### 4.3.1 'Configuration → Device description'

Address	Who
17009	Entry of project-specific device description (max. 16 characters)

### 4.3.2 'Configuration → Temperature control'

#### Temperature setpoint values

Entry of temperature setpoint values for heating and cooling for Occupied and Unoccupied modes. The range between the setpoint value for heating and the setpoint value for cooling is the comfort temperature range.




Fig. 27: Comfort temperature range

- Red Comfort temperature range for Occupied
- blue Comfort temperature range for Unoccupied
- 1 Room temperature setpoint value
- 2 Occupied
- 3 Unoccupied
- 4 Cooling setpoint value for Unoccupied
- 5 Heating setpoint value Unoccupied
- 6 Heating setpoint value for Occupied
- 7 Cooling setpoint value for Occupied

Address	Who
17322	Cooling temperature setpoint value for Occupied
17323	Heating temperature setpoint value for Occupied
17324	Cooling temperature setpoint value for Unoccupied
17325	Heating temperature setpoint value for Unoccupied



For values marked with [1/10 °C], the values are always entered with a factor of 10.

**Example:** 17322 cooling temperature setpoint value for Occupied = 26 °C

**Entry :** 260

### Supply air temperature limits

Entry of minimum and maximum supply air temperature for Occupied and Unoccupied modes.

Address	Who
17311	Supply air temperature upper limit for Unoccupied
17309	Supply air temperature lower limit for Unoccupied
17310	Supply air temperature upper limit for Occupied
17308	Supply air temperature lower limit for Occupied

### Winter compensation

Entry of parameters for the winter compensation function.

Address	Who
11478	Activation of winter compensation 0 = Winter compensation inactive 1 = Winter compensation active
17479	Entry of start temperature
17480	Entry of end temperature
17481	Entry of maximum setpoint value increase

### Temperature sensor offset



The temperature sensor offset is used as a corrective value when there are temperature deviations.

The entered value is a constant and always has the same effect.

**Recommendation:** Offset = 0

Address	Who
17273	Entry of supply air temperature sensor correction
17276	Entry of room temperature sensor correction

### 4.3.3 'Configuration' → 'Clock and timer'

#### Current date and time on the device

Display of the date and time saved on the FSL-CONTROL III controller.

#### Set internal clock

Decentralised ventilation unit from TROX can be delivered from the factory with the pre-set date and time. However, it can be necessary to change settings or correct deviations.

Address	Who
10008	Default current date
10010	Default current time
10007	Set date and time 0 = No takeover 1 = Transfer to the controller
18077	Summertime setting 0 = Inactive 1 = Active



#### Number format

**Date:** ddmmyy [6 digits without separators]

**Time:** hhmmss [6 digits without separators]

The data is taken over by entering "1" and Return in the input field (address 10007).

#### Weekly program

An individual profile can be selected for each weekday.

Address	Who
18000	Profile for Monday
18001	Profile for Tuesday
18002	Profile for Wednesday
18003	Profile for Thursday
18004	Profile for Friday

Address	Who
18005	Profile for Saturday
18006	Profile for Sunday

## Profile 1 – 7

For each profile, 10 different switching points can be freely selected.

The following operating modes and overrides are available:

- 1 - Standby
- 2 - Unoccupied
- 3 - Occupied
- 4 - Boost
- 5 - Exercise
- 6 - Night ventilation
- 7 - Fan force

Address	Who
18007	Switching point 1
18008	Switching point 2
18009	Switching point 3
18010	Switching point 4
18011	Switching point 5
18012	Switching point 6
18013	Switching point 7
18014	Switching point 8
18015	Switching point 9
18016	Switching point 10



*Always start the profile entry at 00:00 in 'Unoccupied' mode,*

*We recommend separate profiles for weekdays, weekends and holidays.*

*For supply air temperature control, please replace the operating mode 'Unoccupied' with 'Standby'. The switching points are always active until the following switching point is reached.*

*Entry is always a combination of time and operating mode or override.*

*Prefixed zeros are not displayed after entry.*

**Example 1:** entry of Unoccupied at 00:00

*Entry = 00002 Display = 2*

**Example 2:** Entry of Night purge at 02:00

*Entry = 2006 Display = 2006*

## Example for office

Office hours: 8:00 am – 5:00 pm

12:00 am - Start Unoccupied ⇒ 2

2:00 am - Start Night purge ⇒ 2006

5:00 am - End Night purge (Unoccupied) ⇒ 5002

7:00 am - Pre-tempering (Occupied) ⇒ 7003

7:45 am - Flush with fresh air (Boost) ⇒ 7454

8:00 am - Normal operation (Occupied) ⇒ 8003

12:30 pm - Lunch (Unoccupied) ⇒ 12302

1:30 pm - Normal operation (Occupied) ⇒ 13303

5:00 pm - Unoccupied ⇒ 17002

9:00 pm - Rep. Unoccupied ⇒ 21002



## Further information

🔗 3.1.2.9 'Operating modes / operating mode override' on page 20

## 4.3.4 'Configuration → Fan control'

### Air quality control (optional)

Air quality control means that the outdoor air flow rate is controlled based on the room air quality.

This type of control is only possible with an air quality sensor (optional equipment or by others). The internal sensor optionally detects the CO<sub>2</sub> concentration or the VOC content of the extract air. Air quality control is always active in the 'Occupied' operating mode. In the 'Unoccupied' operating mode, air quality control is inactive.

Activation of the function in the 'Unoccupied' operating mode in address line 17378.

The switching thresholds apply for both 'Occupied' and 'Unoccupied' operating modes. If a switching threshold is exceeded, the configured fan stage is activated.

**i Secondary air function**

For devices with secondary air switching, secondary operation is active until the first switching threshold is reached. If the air quality measured value exceeds the first switching threshold, supply air and extract air operation is activated. When the other switching thresholds are reached, the fan speed is increased.

Address	Who
17378	Enable air quality control in Unoccupied 0 = Inactive 1 = Active
17380	First switching threshold for air quality 0..2000 ppm
17381	Second switching threshold for air quality 0..2000 ppm
17382	Third switching threshold for air quality 0..2000 ppm
17383	Fourth switching threshold for air quality 0..2000 ppm
17384	Fifth switching threshold for air quality 0..2000 ppm

**i Recommended**

- Limit value for first fan stage: 500 ppm
- Limit value for second fan stage: 750 ppm
- Limit value for third fan stage: 900 ppm
- Limit value for fourth fan stage: 2100 ppm
- Limit value for fifth fan stage: 2100 ppm

**Humidity control**

Humidity control is currently not supported.

**4.3.5 'Configuration → Interfaces'**

Address	Who
10003	Device restart 0 = No default 1 = Restart

**i Device restart**

To change some settings, the controller will need to be restarted. To restart, enter 1 in the input field for address 10003 and confirm with Return.

**Slave devices**

Address	Who
17048	Entry of the number (!) of connected devices  For master in combination with one slave = 1, for several slaves = number of slaves. For slave devices, the value corresponds to the number of following slave devices.

**Settings SL1 connection X1 serial bus**

The connection SL1 / terminal X1 is used in master devices to connect devices to the central building management system.

1 – 127 is available as the address range. A serial bus string can consist of max. 32 subscribers. With slave devices, the master device is connected at connections SL1 / terminal X1.

**i Factory-set Modbus address**

Modbus address 2 is entered in the factory. In the case of connection from a master device to exactly 1 slave device, no settings are required. If several slave devices are connected to a master device: for every slave device connected, the Modbus address is incremented by "1".

- Example slave 1 = Modbus address terminal X1 = 2
- Slave 2 = Modbus address terminal X1 = 3
- Slave n = Modbus address terminal X1 = n + 1

Addr.	Who	Explanation
16124	Entry of Modbus address terminal X1	
16125	Serial protocol type 3 = Modbus RTU 4 = BACnet MS/TP	

Addr.	Who	Explanation
16129	Baud rate X1 (RS485-1) 0 = 9600 1 = 19200 2 = 38400 3 = 57600 4 = 76800 baud	For master devices that correspond to the serial bus system provided by others  For slave devices, the baud rate is exclusively 38400 baud (value = 2).
16126	Data bits X1 (RS485-1)	For master devices that correspond to the serial bus system provided by others  For slave devices, the number of data bits is exclusively 8 (value = 8).
16127	Stop bits X1 (RS485-1)	For master devices that correspond to the serial bus system provided by others  For slave devices, the number of stop bits is exclusively 1 (value = 1).
16128	Parity X1 (RS485-1) 0 = Neutral 1 = Odd 2 = Even	For master devices that correspond to the serial bus system provided by others  For slave devices, the parity is exclusively Even (value = 2)

## Settings SL2 connection X2 serial bus

The connection SL 2 / terminal X2 is used for master devices to connect the first slave devices

The Modbus address SL 2 / terminal X2 is always 1, no settings are needed.

Address	Who
15774	Address

## IP address

The input fields are used to set the IP address of the FSL-CONTROL III controller. For the entry, the IP address is divided into four address blocks (points).

### Entry of IP address

IP-Adresse: 10.2.100.242  
  
 IP-Adressblock: 1 2 3 4

IP address factory setting

Master devices - 10.2.100.242

Slave devices - 10.2.100.243

Address	Who
15798	IP address block 1
15799	IP address block 2
15800	IP address block 3
15801	IP address block 4

### Access with PC and web browser

Connect the ventilation unit and PC with a patch cable and enter the IP address into the address line of the web browser to get access to the ventilation unit. Here, conditions can be checked, values can be read out and settings can be configured.

## Accepting network settings

Address	Who
10023	To accept changes to the factory preset IP address, IP gateway and IP network mask, please confirm with "1" and Return.

## IP gateway

The address of the IP gateway is entered in the input fields. The input syntax follows the IP address; see ['IP address' on page 40](#).

Address	Who
15802	IP gateway block 1
15803	IP gateway block 2
15804	IP gateway block 3
15805	IP gateway block 4

## IP network mask

The address of the IP network mask is entered in the input fields. The input syntax follows the IP address; see ['IP address' on page 40](#).



Address	Who
15802	IP network mask block 1
15803	IP network mask block 2
15804	IP network mask block 3
15805	IP network mask block 4

### BACnet



*In BACnet, the instance number is displayed as the sum of BACnet identifier + 65536. The BACnet ObjectName describes the device name in BACnet.*

*In addition, the BACnet identifier and BACnet Object\_Name can be used for their own settings. Please ensure uniqueness in the network.*

Address	Who
17565	Enter the BACnet identifier as an integer. In BACnet, the identifier is displayed as the instance number according to the logic "65536" + BACnet identifier. E.g.: Address 17565 = 7, instance = 65536 + 7 = 65543.
17570	The BACnet Object Name is displayed as the device name.

### 4.3.6 'Configuration → Temperature control\*+'

#### Basic settings

Address	Who
17305	Control strategy 0 = Supply air temperature control For isothermal introduction of the supply air. Devices only cover the ventilation heat loss. It is important that the integrated extract air temperature sensor is activated, otherwise room air/extract air frost is active. 1 = Room temperature control In connection with room temperature via CP or central BMS. 2 = Extract air temperature control In conjunction with integrated extract air temperature sensor.

Address	Who
17306	Register type 0 = No register 1 = Changeover In Changeover mode, the device requires information about the medium via DI or the central BMS. If no information is available, the valves are not controlled. 2 = 2-pipe heating Also enter for isothermal supply air intake. 3 = 2-pipe cooling 4 = 4-pipe heat exchanger 5 = Electric heating register only for SCHOOLAIR-V-HV-EH.
17327	Minimum outdoor temperature to enable the active cooling sequence presetting: 10°C]
17328	Delay in switchover between heating and cooling presetting: 1 min.
17110	Room / extract air temperature deviation for max. fan speed presetting: 3 K. This means that, if the deviation is > 3 K, the devices switch to the third fan stage. All other stages according to the resulting characteristic curve.

#### Temperature setpoint values

Address	Who
17322 – 17325	↪ 'Temperature setpoint values' on page 36
17318	Hysteresis threshold for supply air temperature presetting: 0.2 K; i.e., the supply air temperature may deviate from the specified supply air temperature by this value.

#### Master controller

The master controller affects the deviation between the setpoint and actual room temperature. The valves are not affected at this point. Settings of the valves via addresses 17312, 17313, 17315, 17316.

Address	Who
17319	Cascade control proportionality coefficient presetting: 15
17320	Cascade control integration time presetting: 400

## Supply air temperature limits

Address	Who
17311	Entry of the supply air temperature upper limit for Unoccupied
17309	Entry of the supply air temperature lower limit for Unoccupied
17310	Entry of the supply air temperature upper limit for Occupied
17308	Entry of the supply air temperature lower limit for Occupied

## Winter compensation

Address	Who
17478	<p>Winter compensation enable 0 = inactive 1 = active (default)</p> <p>Entry of the parameters for winter compensation via addresses 17479, 17480 and 17481.</p>

## Cooling coil

Address	Who
17312 – 17330	No changes to the presettings are required.

## Heat recovery

Address	Who
17336	<p>HRU type</p> <p>1 = Plate-type HRU Setting for the following unit types:</p> <ul style="list-style-type: none"> <li>■ All FSL units</li> <li>■ SCHOOLAIR-B</li> <li>■ SCHOOLAIR-B-HE</li> <li>■ SCHOOLAIR-V-0-2L / -4L</li> <li>■ SCHOOLAIR-V-1800</li> <li>■ SCHOOLAIR-V-HE</li> <li>■ SCHOOLAIR-D-0-2L / -4L</li> </ul> <p>2 = Rotary heat recovery unit Setting for the following unit types:</p> <ul style="list-style-type: none"> <li>■ SCHOOLAIR-B-HV</li> <li>■ SCHOOLAIR-V-HV</li> <li>■ SCHOOLAIR-V-HV-EH</li> <li>■ SCHOOLAIR-D-HV</li> </ul>
17337	<p>HRU proportionality coefficient No changes to the presettings are required.</p>

Address	Who
17338	HRU integration time: No changes to the presettings are required.
17339	<p>HRU throughout the year 0 = inactive For all devices with a plate-type heat recovery unit and without a condensate drain. Condensate is avoided because the bypass opens when the outdoor temperature is too cold and the air goes directly to the heat exchanger. The available water-side output must cover the entire ventilation heat loss. 1" = Active Basically for all *-HV unit variants, as the rotary heat recovery unit does not generate any condensate to the outside. A condensate connection is mandatory for devices with plate-type heat recovery units. In addition, the frost protection cycle (Configuration -&gt; Frost protection*) must be activated.</p>
17340	Minimum setpoint value of HRU: No changes to the presettings are required.
17341	Maximum setpoint value of HRU: No changes to the presettings are required.
17344	<p>Heat recovery rate of HRU Settings as follows:</p> <p>60%</p> <ul style="list-style-type: none"> <li>■ All FSL units</li> <li>■ SCHOOLAIR-B-0-2L / -4L</li> <li>■ SCHOOLAIR-V-0-2L / -4L</li> <li>■ SCHOOLAIR-V-1800</li> <li>■ SCHOOLAIR-D-0-2L / 4L</li> </ul> <p>84%</p> <ul style="list-style-type: none"> <li>■ SCHOOLAIR-B-HE</li> <li>■ SCHOOLAIR-V-HE</li> </ul> <p>75%</p> <ul style="list-style-type: none"> <li>■ SCHOOLAIR-B-HV</li> <li>■ SCHOOLAIR-V-HV</li> <li>■ SCHOOLAIR-D-HV</li> </ul>
17342	Minimum temperature difference: No changes to the presettings are required.
17343	Waiting time if there are favourable temperature conditions

## Heating coil

Address	Who
17315 – 17316 17331 – 17332	No changes to the presettings are required.

**Electric heating register**

Address	Who
17378	Electric heating register Dynamic enable Dynamic influences the maximum heating capacity of the electric heating register depending on the outdoor air temperature and the fan stage. 0 = inactive 1 = Active Only for SCHOOLAIR-V-HV-EH.
17579	Electric heating register proportion Dynamic Information on proportion Dynamic.

**Temperature sensor offset**

For the correction of various temperature sensors. Please make sure that the offset affects the entire temperature range.

Address	Who
17273	Supply air temperature offset
17274	Outdoor air temperature offset
17276	Room air temperature offset Insofar as a correction of the measurement must be made in the control panel. Please check the installation location of the control panel.
17277	Extract air temperature offset Input AI8 is used here, which is always used for extract air temperature if the extract air temperature sensor is an NTC 10k, i.e., for all CO2 / temperature combination sensors.
17278	Return temperature offset
17279	Flow temperature offset
17280	Extract air temperature Input AI12 is used here, which is always used for the extract air temperature if the extract air temperature sensor emits a 0...10 VDC signal, i.e., for all CO2 / humidity / temperature combination sensors. Primarily in FSL-U-ZAS.

**4.3.7 'Configuration → Air control\*+'**

**Air quality control**

Address	Who
17290	Type of sensor 0 = None, for all slaves. For master devices, if the integrated CO2 sensor is not used. 1 = IAQ2000 Not included in delivery. 2 = Titec CO2 The devices are supplied with a CO2 sensor as standard. 3 = Titec VOC
17376	Air quality control enable 0 = Inactive For master devices without an internal sensor or on-site sensor, including transmission via the central BMS. 1 = Active For master devices with integrated sensors and for master devices without internal sensors with simultaneous transmission of measured values via the on-site central BMS. The master decides itself which fan stage is active based on the measured values.
17377	Enable air quality control enable in Occupied 0 = Inactive during Occupied 1 = Active during Occupied (= default setting)
17378	Enable air quality control in Unoccupied 0 = Inactive during Unoccupied (= default setting) 1 = Active during Unoccupied
17111	Outdoor air automatic 0 = Inactive If the measured value for the indoor air quality is below the first threshold value, the device ventilates with secondary air in Occupied. 1 = Active Regardless of the indoor air quality, the device always ventilates with outside air when it is present.
17380	First switching threshold for air quality If the measured value is below the first switching threshold, the device ventilates with secondary air, provided that outdoor air automatic = 0. If the measured value is above the first switching threshold, the device ventilates with outdoor air. Fan stage = Stage 1.
17381	Second switching threshold air quality If the measured value is above the second switching threshold, the device ventilates with outdoor air in the second stage.
17382	Third switching threshold air quality If the measured value is above the third switching threshold, the device ventilates with outdoor air in the third stage.

Address	Who
17383	Fourth switching threshold air quality If the measured value is above the fourth switching threshold, the device ventilates with outdoor air in the fourth stage.
17384	Fifth switching threshold air quality If the measured value is above the fifth switching threshold, the device ventilates with outdoor air in the fifth stage.

## Humidity control

Humidity control is not currently supported.

## Fan stages

Address	Who
17072	Minimum fan stage during Occupied 1 = Default setting, fans always run during Occupied.
17074	Maximum fan stage during Occupied 3 = Default setting; this setting limits the available fan stages to 3 stages during Occupied.
17071	Minimum fan stage during Unoccupied 0 = Default setting, the fans can be switched off provided that the room temperature is within the set point range.
17073	Maximum fan stage during Unoccupied 4 = Default setting; this setting limits the available fan stages to 4 stages during Unoccupied. The fourth fan stage is activated during Night Purge.
17112	Reduction in fan stage temperature without cooling If the devices are not cooling (2-pipe - heating), this parameter can be used to reduce the fan stage so that the rooms are not heated up too much when the outdoor temperatures are too high.

## Operating mode override settings

Address	Who
17462	Boost enable 0 = inactive 1 = Active
17463	Fan level during Boost; entry of the active fan stage for Boost mode. Default stage = stage 4. During Boost, ventilation always uses with outdoor air.
17467	Exercise enable 0 = inactive 1 = Active

Address	Who
17468	Fan level during Exercise; entry of the active fan stage for Exercise mode. Default stage = stage 2. During Exercise, ventilation always uses with outdoor air.
17450	Night Purge enable 0 = inactive 1 = Active
17456	Fan level during Night Purge; entry of the active fan stage for Night Purge mode. Default stage = stage 4. During Exercise, ventilation always uses with outdoor air. Activation via RTC or central BMS required.
17472	Enable Fan Force mode operation For combination with fume cupboards or separate, time-limited extract air. 0 = inactive 1 = Active Activation is always via DI or central BMS.
17473	Fan stage, Fan Force mode, supply air, entry of fan stage for supply air fan.
17474	Fan stage, Fan Force mode, extract air, entry of fan stage for extract air fan. The stage should always be > 0.

## Electric heating register

Address	Who
17105	Minimum time in current fan stage To prevent the device from jumping too quickly between different stages.
17061	Outside damper running time The fans are only put into operation after this time has elapsed. No change required.
17359	Locking time secondary air - fresh air changeover The device can only switch from outdoor air mode to secondary air mode, or vice versa, after this locking time has elapsed.

### 4.3.8 'Configuration → Secondary air addition damper\*+'

These settings are only necessary for the FSL-U-ZAS.

**Secondary air damper**

Address	Who
17345	Secondary air damper enable 0 = inactive 1 = Active Secondary air damper must be active.
17352	Minimum resting time in current direction of action No changes possible.

**Condensate prevention**

The FSL-U-ZAS does not require a condensate drain, as condensate forming is prevented by the temperature control. For this purpose, the air temperature upstream of the heat recovery unit is raised by mixing in secondary air to such an extent that no condensate is formed.

Address	Who
17346	Prevention of condensation - minimum temperature difference (between extract air and outdoor air temperature) for activation Default setting = 5 K. No change required. The outdoor air must be at least 5 K cooler than the extract air temperature.
17347	Prevention of condensation - temperature offset with regard to the calculated minimum mixed air temperature Default setting = 2 K. For safety, the mixing air temperature to be achieved is raised by 2 K and therefore more secondary air is added.
17349	Maximum total control input signal of supply air fan For mixing, the control voltage of the supply air fan is increased so that it draws in more air in total. This value limits the maximum possible control voltage for acoustic reasons.

**Mixed air temperature control**

Address	Who
17330 – 17351	No change required.

**Fan stages**

These settings affect the fan stages in regard to air quality.

Address	Who
17106	Minimum outdoor air stage Default setting = 1 The device always ventilates with outdoor air at stage 1 during Occupied mode. This means that pure secondary air operation is not possible during Occupied.
17107	Maximum outdoor air stage Default setting = 3 For limiting the fan stage with outdoor air. If further fan stages are permitted, the difference is covered by secondary air.
17109	Maximum supply air - extract air Default setting = 3

**4.3.9 'Configuration  
→ Secondary air addition fan\*+'**

These settings are only necessary for the FSL-B-ZAB +SEK.

**Secondary air fan**

Address	Who
17354	Secondary air fan enable 0 = inactive 1 = Active The secondary air fan must be activated.

**Fan stages**

Address	Who
17355	Minimum secondary air stage Default setting = 1. This means that the secondary air fan always runs at stage 1 so that the supply air is not forced back by the secondary air fan.
17356	Maximum secondary air stage Setting according to the number of fan stages. .
17108	Minimum supply/extract air stage To ensure the minimum outdoor air volume. Usually stage 1
17109	Maximum supply/extract air stage Setting according to the number of fan stages. If a maximum outdoor air volume has been defined in the project, this volume can be set here.

Configuration menu &gt; 'Configuration è Characteristics\*+'

#### 4.3.10 'Configuration → Characteristics\*+'

##### Control input signal fan supply air

Address	Who
17080 – 17084	For entering the control voltage of the supply air fan for up to 5 stages. Stage 1 – 3 represent normal operation, Stage 4 for Boost and Night Purge. Control voltages according to table, ↗ 'Control voltages ' on page 47 .

##### Volume flow rate fan supply air

Address	Who
17075 – 17079	For entering the volume flow rate in the individual fan stages for supply air. This value is output to the central BMS.

##### Control input signal fan control extract air

Address	Who
17090 – 17094	For entering the control voltage of the extract air fan for up to 5 stages. Stage 1 – 3 represent normal operation, Stage 4 for Boost and Night Purge. Control voltages according to table, ↗ 'Control voltages ' on page 47 .

##### Volume flow rate fan extract air

Address	Who
17075 – 17079	For entering the volume flow rate in the individual fan stages for extract air. This value is output to the central BMS.

##### Control input signal fan secondary air

Address	Who
17095 – 17099	For entering the control voltage of the secondary air fan for up to 5 stages.

**Control voltages**
**SCHOOLAIR-B control voltages [V]**

Volume flow rate		SA-B-0		SA-B-HE		SA-B-HV	
(m³/h)	[l/s]	ZUL (SUP)	FOL (EHA)	ZUL (SUP)	FOL (EHA)	ZUL (SUP)	FOL (EHA)
150	42	42	40	26	29	26	29
200	56	52	50	32	37	30	33
250	69	62	60	39	44	34	37
300	83	72	70	45	52	38	41
320	89	76	74	47	56	39	43
350	97			51	60	42	45
400	111			58	68	46	49
450	125			64	76	49	54
500	139					53	58
550	153					57	62
600	167					61	66

**SCHOOLAIR-V control voltages [V]**

Volume flow rate		SA-V-0-2L / -4L		SA-V-1800-2L / -4L		SA-V-HE-2L / -4L		SA-V-HV-2L / -4L		SA-V-HV-EH	
(m³/h)	[l/s]	ZUL (SUP)	FOL (EHA)	ZUL (SUP)	FOL (EHA)	ZUL (SUP)	FOL (EHA)	ZUL (SUP)	FOL (EHA)	ZUL (SUP)	FOL (EHA)
150	42	44	44	40	43	27	25	29	26	29	26
200	56	56	56	50	53	35	32	33	30	33	30
230	64	64	64	56	59	39	37	36	33	36	33
240	67	66	66	58	61	41	38	37	34	37	34
250	69	68	68	60	63	42	40	38	34	38	34
280	78	76	76	66	69	47	44	40	37	40	37
300	83	80	80	70	73	50	47	42	38	42	38
320	89	85	85	74	77	52	50	44	40	44	40
350	97			80	83	57	55	46	42	46	42
360	100					58	56	47	43	47	43
400	111							51	46	51	46
450	125							55	50	55	50
500	139							60	54	60	54
550	153							64	58	64	58
600	167							68	62	68	62

**SCHOOLAIR-D control voltages [V]**

Volume flow rate		SA-D-0		SA-D-HV	
(m³/h)	[l/s]	ZUL (SUP)	FOL (EHA)	ZUL (SUP)	FOL (EHA)
150	42	49	53		
200	56	63	66		
250	69	76	80	21	18
300	83	90	94	25	22
320	89	95	100	26	23
400	111			32	29
500	139			38	36
600	167			45	43
700	194			52	51
800	222			59	58
900	250			66	65
1000	278			73	72
1100	306			79	79

**FSL device control voltages [V]**

Volume flow rate		FSL-U-ZAS		FSL-B-ZAB+SEK		
(m³/h)	[l/s]	ZUL (SUP)	FOL (EHA)	ZUL (SUP)	FOL (EHA)	SEK
60	17	28	30	19	21	31
90	25	39	40	31	32	39
120	33	49	51	43	44	47
150	42	59	61			

**Heating valve characteristic**

The settings depend on the valve-valve drive combination used.

Actuator	Valve					
	Siemens			Frese		
Möhlenhoff, thermoelectric	X			X		
Siemens SSP 61, electromotorised		X			X	
Möhlenhoff, electromotorised			X			X
Address 17229	100	0	100	0	100	0
Address 17230	13	100	0	100	0	100

**Characteristic bypass/rotary heat exchangers**

The settings depend on the design implementation in the device.



Please note the following table:

#### Rotary HRU (SCHOOLAIR-B / -V / -D – HV)

Address	Who
17231	AO2 characteristic min. = 22
17232	AO2 characteristic max. = 100

#### Plate-type HRU (all other device variants)

Address	SA-B-2L/4L	SA-V-2L/4L	SA-V-1800-2L/4L	SA-V-HE-2L/4L	SA-D-2L/4L
17231	100	100	0	100	0
17232	0	0	100	0	100

#### Note

During the function test (service tool), the control input signal of the heat recovery unit has the following meaning:

100% - 100% bypass / 0% HRU

0% - 0% bypass / 100% HRU

Special case SCHOOLAIR-V-0-2L / -4L: Damper open = 100% heat recovery!

#### Cooling valve characteristics

Address	Who
17239 – 17340	Usually, the same settings must be made here as for the heating valve.

#### Characteristic secondary air damper on AO5

Please note that the LED for the CP is connected to AO5, exception: FSL-U-ZAS.

Address	Who
17237	AO5 characteristic min. = 0
17238	AO5 characteristic max. = 60 Limitation to 6 VDC, as the LED at the CP is operated with 5 VDC.

#### Characteristic secondary air damper on AO7

Address	Who
17241	AO7 characteristic min. = 0
17242	AO7 characteristic max. = 100

#### 4.3.11 'Configuration → IO connections\*+'

The configuration described below represents the standard wiring of decentralised ventilation units. Deviations are documented with the wiring diagrams.

#### Occupancy analogue inputs

Address	Who
17177	Occupancy AI1 = 1 (Supply air temperature, NTC 10k)
17178	Occupancy AI2 = 2 (Outdoor air temperature, NTC 10k)
17179	Occupancy AI3 = 8 (CO2 sensor, 0 ... 10 VDC signal)
17180	Occupancy AI4 = 9 (Humidity sensor, 0 ... 10 VDC signal)
17181	Occupancy AI5 = 12 (Analogue control panel setpoint value adjuster, 5k)

Address	Who
17182	Occupancy AI6 = 13 (Analogue control panel fan stage selector or push button)
17183	Occupancy AI7 = 14 (Analogue CP, room temperature, NTC 10k or 20k)
17184	Occupancy AI8 = 6 (Extract air temperature, NTC 10k)
17185	Occupancy AI9 = 5 (Return temperature, NTC 10k)
17186	Occupancy AI10 = 4 (Flow temperature, NTC 10k)
17187	Occupancy AI11 = Currently not in use
17188	Occupancy AI12 = 7 (Extract air temperature, 0 ... 10 VDC signal, FSL-U-ZAS!)
17189	Occupancy AI13 = 3 (Mixed air temperature, NTC 10k, FSL-U-ZAS)
17190	Occupancy AI14 = Currently not in use

## Occupancy analogue outputs

Address	Who
17219	Occupancy AO1 = 1 (Heating valve, 0 ... 10 VDC)
17220	Occupancy AO2 = 5 / 7 (Bypass damper / rotary HRU)
17221	Occupancy AO3 = 3 (Fan supply air, 0 ... 10 VDC)
17222	Occupancy AO4 = 4 (Fan extract air, 0 ... 10 VDC)
17223	Occupancy AO5 = 14 (LED control panel, 0 ... 10 VDC)
17224	Occupancy AO6 = 2 (Cooling valve, 0 ... 10 VDC)
17225	Occupancy AO7 = 6 (Fan secondary air, 0 ... 10 V)
17226	Occupancy AO8 = 1 (Output volume flow rate, 0 ... 10 VDC)
17227	Occupancy AO9 = Currently not in use
17228	Occupancy AO10 = Currently not in use

## Occupancy digital inputs

Address	Who
17116	Occupancy DI1 = 1 (Speed signal fan supply air)

Address	Who
17117	Occupancy DI2 = 2 (Speed signal fan extract air)
17118	Occupancy DI3 = Currently not in use
17119	Occupancy DI4 = 10 (occupancy push button) Wiring: Open = valid operating mode (RTC, DI, central BMS) Closed = Occupied

## Occupied

Address	Who
17120	Occupancy DI5 = 5 (window contact) Wiring: Open = Device OFF, Closed = Automatic
17121	Occupancy DI6 = 6 (fire emergency stop) Wiring: Open = Device OFF, Closed = Automatic
17122	Occupancy DI7 = 7 (external enable) Wiring: Open = Device OFF, Closed = Automatic
17123	Occupancy DI8 = 8 (changeover) Wiring: Open = Heating, Closed = Cooling
17124	Occupancy DI9 = 9 (frost protection monitors)
17125	Occupancy DI10 = 4 (filter pressure monitoring)
17126	Occupancy DI11 = 11 (Night Purge)
17127	Occupancy DI12 = 12 (Fan Force) Wiring: Open = Inactive Closed = Active
17128	Occupancy DI13 = 2 (currently not in use)
17129	Occupancy DI14 = 2 (currently not in use)
17130	Occupancy DI15 = 2 (currently not in use)
17131	Occupancy DI16 = 2 (currently not in use)

## DI

NC-NO contacts

Normally Closed - 0

Normally Open - 1

To perform the functions correctly, the DIs must be configured as follows.

Address	Who
17132	DI1 switch type = 1
17133	DI2 switch type = 1
17134	DI3 switch type = 1
17135	DI4 switch type = 1
17136	DI5 switch type = 0
17137	DI6 switch type = 0
17138	DI7 switch type = 1
17139	DI8 switch type = 0
17140	DI9 switch type = 1
17141	DI10 switch type = 1
17142	DI11 switch type = 1
17143	DI12 switch type = 1
17144	DI13 switch type = 1
17145	DI14 switch type = 1
17146	DI15 switch type = 1
17147	DI16 switch type = 1

**Occupancy digital outputs**

Address	Who
17153	Occupancy DO1 = 1 (shut-off dampers)
17154	Occupancy DO2 = 2 (A alarm) Wiring: Open = Inactive Closed = A alarm present
17155	Occupancy DO3 = 3 (B alarm) Wiring: Open = Inactive Closed = B alarm present
17156	Occupancy DO4 = 4 (operational readiness) Wiring: Open = Inactive Closed = Device active
17157	Occupancy DO5 = Currently not in use
17158	Occupancy DO6 = 7 (heating request, related to the valve)
17159	Occupancy DO7 = 8 (cooling request, related to the valve)
17160	Occupancy DO8 = Currently not in use
17161	Occupancy DO9 = Currently not in use

Address	Who
17162	Occupancy DO10 = 11 (heating request/enable, related to the room) Wiring: Open = Inactive Closed = Enable for external heat transfer fluid
17163	Occupancy DO11 = 12 (cooling request/enable, related to the room) Wiring: Open = Inactive Closed = Enable for external coolant
17164	Occupancy DO12 = Currently not in use

**DO occupancy digital outputs**

NC-NO contacts

Normally Closed - 0

Normally Open - 1

To perform the functions correctly, the DOs must be configured as follows.

Address	Who
17165	DO1 switch type = 1
17166	DO2 switch type = 1
17167	DO3 switch type = 1
17168	DO4 switch type = 1
17169	DO5 switch type = 1
17170	DO6 switch type = 1
17171	DO7 switch type = 1
17172	DO8 switch type = 1
17173	DO9 switch type = 1
17174	DO10 switch type = 1
17175	DO11 switch type = 1
17176	DO12 switch type = 1

Configuration menu &gt; 'Configuration è Device configuration\*...

To implement the wiring of the DI / DO according to the wiring documents:

X3	Function	Open	Closed	Cable breakage resistance	Physical address controller	Used for		DI switch type	
						Address		Address	
1	Fume cupboard switch	Inactive	Active		DI 12	17127	12	17143	1
2	Changeover	Heating	Cooling	Yes	DI 8	17123	8	17139	0
3	Operating enable	Off	Automatic		DI 7	17122	7	17138	1
4	Fire emergency stop	Off	Automatic	Yes	DI 6	17121	6	17137	0
5	Window contact	Off	Automatic	Yes	DI 5	17120	5	17136	0
6	PIR sensor	Valid operating mode	Occupied		DI 4	17125	10	17141	1

X5	Function	Open	Closed	Cable breakage resistance	Physical address controller	Used for		DI switch type	
						Address		Address	
1	Coolant request	Inactive	Active		DO7	17159	7	17171	0
2	Heat transfer fluid request	Inactive	Active		DO6	17158	6	17170	0
3	Operational readiness	Device inactive	Device active		DO4	17156	4	17168	0
4	B Alarm	No alarm	Alarm		DO3	17155	3	17167	1
5	A alarm	No alarm	Alarm		DO2	17154	2	17166	1
6	Enable of heating function, room-related	No release	Release		DO10	17162	11	17174	0
6	Enable of cooling function, room-related	No release	Release		DO11	17163	12	17175	0

#### 4.3.12 'Configuration → Device configuration\*+'

Please restart the controller after making any changes!

Address	Who
17036	FSL-CONTROL III device type 1 = Secondary air units (e.g. FSL-U-SEK) 2 = Supply and secondary air unit with separate secondary air fan (currently not available) 3 = Supply and secondary air unit (SEK via mixing damper), (e.g. FSL-U-ZUS) 4 = Supply and extract air unit (almost all FSL and SCHOOLAIR devices) 5 = Supply and extract air unit with admixture of secondary air (e.g. FSL-U-ZAS, FSL-B-ZAB+SEK)
17042	Master enable  This setting determines whether the device is a master (1) or a slave (0) device.

Address	Who
	1 = Master 0 = Slave
17358	Secondary air changeover enable 1 = Active 0 = inactive Usually activated
17046	Control panel type 0 = No CP All master devices without a control panel. Often in case of connection to the central BMS. Instead of room temperature control, extract air temperature can also be activated. Fundamentally for all slave devices  1 = Digital control panel 2 = Analogue control panel with 20k temperature sensor - All CPs are surface-mounted CPs with selector switch - All CPs for flush mounting 3 = Analogue control panel with 10k temperature sensor - Schneider STR504
17044	Start operating mode  Refers to the behaviour of the devices after restarting the controller. 1 = Off 2 = Automatic 3 = Manual  Only "2" is permitted here.
17045	Start operating mode  Refers to the behaviour of the devices after restarting the controller. 1 = Standby 2 = Unoccupied 3 = Occupied  "3" must be selected here.
17047	Number of IO modules  Currently only applies to FSL-U-ZAS and FSL-B-ZAB+SEK with 4-pipe heat exchanger and control panel connection. In this case, the IOs on the controller are not sufficient and an additional module is required. Only then is a "1" to be entered here.  Default setting = 0.

Address	Who
17450	Night Purge enable 0 = Night Purge inactive 1 = Night Purge active
17451	Start month  To determine the period during which Night Purge may be carried out at all.
17452	End month  To determine the period during which Night Purge may be carried out at all.
17453	Minimum outdoor temperature  Setting of the lower limit of the outdoor temperature.
17454	Start delta outdoor temperature cooling set-point value  The outdoor temperature must be lower than the cooling setpoint value for Occupied by this amount.
17455	Stop delta outdoor temperature room temperature  If the difference between the outdoor temperature and the room temperature is smaller than the set value, Night Purge is terminated.
17456	Fan stage  Setting of the fan stage during Night Purge. Usually stage 4.
17458	Minimum time for Night Purge  Setting of the minimum duration of Night Purge. Usually 30 minutes.

**Filter monitoring**

Address	Who
17494	Filter monitoring enable 0 = No filter monitoring 1 = Filter monitoring active  No distinction is made here about the type of filter monitoring, but filter monitoring is activated in principle.
17495	Time monitoring of filter change interval Setting of the time span after which the filter change is displayed. Usually 2,500 h.

**4.3.13 'Configuration → Functions\*+'**

**Night purge**

Please note: Night Purge must be additionally activated by either the RTC or the central BMS.

Address	Who
17496	Pressure monitoring Affects all unit types: - HE, HV and HV-EH must be activated. In addition, filter monitoring (4) must be set for DI10 and Normally Closed must be selected as the switch type.
17497	Pressure monitoring message delay Enter the duration for which the pressure monitoring must have been triggered before the message is sent. Usually 30 minutes. For preventing gusts of wind from causing triggering.

## Priming

Address	Who
17422	First month for priming Determination of the months in which priming is carried out.
17423	Last month for priming Determination of the months in which priming is carried out.  Please note that priming is always (!) carried out within this period. We therefore do not use this function, but only the temperature-controlled activation of the priming process.
17415	Minimum outdoor temperature Specifies the outdoor temperature at which the priming process is activated, i.e. priming takes place if the temperature falls below the entered value.
17416	Max. priming time Setting of the duration of the priming process. Usually 3 minutes (180 sec.).
17418	Heating valve setting at the end of the process The valve is set to this value after priming so that the supply air temperature setpoint value is reached more quickly.
17419	Holding tie for heating valve setting After the priming process, the valve is moved to the setpoint value (17418) and held for the duration of the value specified here. Regulation of the supply air temperature does not take place during this period.
17414	Minimum priming duration with return temperature monitoring Currently not in use.
17421	Minimum return temperature for termination Currently not in use.

## Logging

The devices permanently log all existing data. E.g. sensor values, operating status, central BMS.

Address	Who
17558	Logging enable 0 = inactive 1 = Active = Default setting
17562	Number of files 31, i.e., a separate file is created for each day of the month. Thus, the last 31 days are always logged.
17559	Logging interval 20, i.e., data is written every 20 seconds. Please do not make any changes, as the resulting amount of data can still be processed very well.
17561	Lines per file 4320, corresponds to logging every 20 sec within 24 hours.
17560	Lines per write process  10 so that the SD card is not accessed too often.

## FTP

Address	Who
17564	Enable FTP access to the controller 1, the controller can be accessed via the service tool, e.g. for software updates.
16138	FTP volume enable 0 = Flash memory 1 = SD card To read the data from the SD card, "1" must be entered here.

### 4.3.14 'Configuration → Alarms\*+'

Individual alarm messages can be suppressed here. No settings are necessary.

- 0 - The alarm is not output
- 1 - The alarm is output

**4.3.15 'Configuration  
→ Frost protection\*+'**

**Supply air frost protection**

Address	Who
17403	Supply air frost protection start temperature Entry of the minimum supply air temperature. The frost protection function is carried out if the temperature falls below this value. Default value = 8°C
17389	Duration Duration of the frost protection function caused by supply air frost. Default value = 360 seconds
17390	Restart frost protection delta supply air Enter the temperature at which frost protection is exited. Default value = 1K.

**Room frost protection**

Address	Who
17391	Room frost protection start temperature Entry of the minimum room temperature. The frost protection function is carried out if the temperature falls below this value. Default value = 8°C
17392	Duration Duration of the frost protection function caused by room frost. Default value = 360 seconds
17393	Restart frost protection delta room Enter the temperature at which frost protection is exited. Default value = 1K.

**Outdoor temperature frost protection**

Address	Who
17394	Outdoor temperature frost protection Start temperature Enter the minimum outdoor air temperature. The frost protection function is carried out if the temperature falls below this value. Default value = -20°C
17395	Duration Duration of the frost protection function caused by supply air frost. Default value = 900 seconds
17396	Restart frost protection delta outdoor temperature Enter the temperature at which frost protection is exited. Default value = 2K.

**Heat recovery unit frost protection**

Address	Who
17397	HRU frost protection start temperature Entry of the minimum outdoor air temperature: If the value falls below this value, the bypass is opened or the frost protection cycle is carried out (with year-round heat recovery in conjunction with plate-type heat recovery unit). Different values must be set for the different heat recovery systems: Cross-flow HRU = -6°C Cross counterflow HRU = -4°C Rotary HRU = -20°C (rotor does not produce condensate that has to be discharged!)
17399	Duration Duration of the frost protection function caused by HRU frost. Default value = 360 seconds
17398	Delta temperature close bypass Enter the temperature at which the bypass is closed. Default value = 1K.

**HRU frost protection cycle**

Address	Who
17409	Frost protection cycle enable This function enables year-round heat recovery with plate-type heat recovery units. Please note that this function generates condensate and the devices must (!) have a condensate connection. 0 = inactive 1 = Active
17410	Secondary air operating time The secondary air is used to defrost the heat recovery unit if necessary. Default value = 20 minutes.
17411	Outdoor air operating time Definition of the maximum duration in supply air and extract air mode until switching to secondary air. Default value = 180 min. (i.e. switching takes place every 3 h at the latest).

Configuration menu &gt; 'Configuration → Options\*+'

**4.3.16 'Configuration → Control panel\*+'**

Setpoint value adjuster / push button / selector switch The settings can be found in the following table:

Address	Honeywell, 5-stage M546FB8	Schneider STR504 M536BA4	Titec RTF3- NTC20k- P5k-T-L Axx59067	Titec RTF3- NTC10k Axx59069	Thermokon, WRF06- TD-20k Axx81503	Titec BS1- NTC20k- P5k-T-L Axx74476	Thermokon WRF07 PTD NTC20k BTyp6 5k-gn Axx79778 Axx79779 Axx81579
	Value	Value	Value	Value	Value	Value	Value
17425	1	1	1	0	0	1	1
17434	30	30	30	0	30	30	30
17433	-30	-30	-30	0	-30	-30	-30
17436	5500	5500	2650	0	2500	2160	2500
17437	4785	4785	3050	0	3000	2600	3000
17435	100	100	100	0	100	100	100
17426	1	1	1	0	1	1	1
17427	1	1	1	0	1	1	1
17428	1	1	1	0	1	1	1
17424	1	0	1	0	1	1	1

**Times**

Address	Who
17439	Run time of overtime operation Determination of the duration for overtime. Function must be activated, see address 17426 Default value = 60 minutes.
17464	Boost run time Default value = 15 minutes.
17469	Exercise run time Default value = 60 minutes.

**4.3.17 'Configuration → Options\*+'**

For activating / deactivating the internal clock for executing the timers or for enabling the Modbus or BACnet interface to the central BMS. Please ensure that only one interface to the central BMS is active at any one time, provided the devices are connected to a central BMS. These options are chargeable and therefore protected from access with separate passwords.

**4.3.17.1 'Configuration → Overall configuration\*+'**

After commissioning, a protocol with all settings can be generated here. Using the Print command in the browser and the selection of a \*pdf printer, a \*.pdf can be generated and transferred to the customer with the protocol for the commissioning.



## 4.4 Manual control menu

### 4.4.1 'Manual control → Commands'

#### Safety instructions for manual control

**! NOTICE!**

**Damage to property due to manual control!**

In manual control, the safety functions are disabled. The device must be permanently monitored, e.g. as the frost protection monitoring function is disabled.

#### Manual mode

The purpose of manual control is to control actuators individually and to check their functioning. Entries are made exclusively via the web browser. The function test of actuators is carried out on site at the device.

To end manual control, enter 2 (auto) in the address field (address 10000) and then restart the device. To restart the device, enter 1 in the input field (address 10003) and confirm with the Return key.

**i Hydraulic balancing**

*For commissioning, the values can be opened in the manual control operating mode for hydraulic balancing.*

Address	Who
10000	Operating mode: 0 = No default 1 = Off 2 = Auto 3 = Manual
10003	Device restart: 0 = No default 1 = Restart

Device status operating mode 'Off'

- Fans - OFF
- Shut-off dampers - Closed
- Valves - Closed
- Frost control - active
- Digital inputs - Switching deactivated

#### Reset filter hours

After a filter change, the operating hours counter can be reset using this function.

Address	Who
10006	Reset filter operating hours 0 = No default 1 = Perform reset

#### Variables of actuators (only in manual operating mode)

The actuators can be individually started in the manual control operating mode using the following functions.

Address	Who
10012	Bypass/RWT 0..100 [%]
10013	Outside damper 0/100 [%] 0 = Closed 100 = Open
10015	Heating valve 0..100 [%]
10016	Cooling valve 0..100 [%]
10017	Supply air fan Stage 0..5 or information in percent 6..100 [%]
10018	Extract air fan Stage 0..5 or information in percent 6..100 [%]
10019	Secondary air fan Stage 0..5 or information in percent 6..100 [%]

## 4.5 Menu for connection to central BMS

The ventilation units can be connected to the central BMS using Modbus RTU, Modbus TCP, BACnet MS/TP or BACnet IP. All the available data points are displayed via the menu for connection to central BMS. The address in the tables corresponds to the Modbus address.

### 4.5.1 Connection to the central BMS via Modbus

#### 4.5.1.1 Communication commands

Settings for communication via Modbus:

- [↗ Chapter 2.2.2 'Modbus TCP / BACnet IP' on page 15](#)
- IP address for Modbus TCP [↗ 'IP address' on page 40](#)
- Enter 502 as the port.

The following commands are supported by the controller:

Modbus command	Description
03 (0x03)	Read holding registers
16 (0x10)	Write multiple holding registers

#### 4.5.2 'Connection to central BMS → Device => central BMS'



Depending on the software used for communication with the central BMS, an offset must be set and thereby reduce the address by 1.

**Example:** Query of operating status

Software used = Modbus Poll

Address tab = 9102

The following table shows all data points that can be accessed via the web server. The data points are the same as the ones in the Modbus protocol.

no.	Address	Who	Notes
1	9100	eOutOperatingMode Operating mode	Output operating mode 1 = Off 2 = Automatic mode 3 = Manual mode
2	9101	eOutOperatingType Operating mode	Output operating mode 0 = No operating mode 1 = Standby 2 = Unoccupied 3 = Occupied
3	9102	fOutOperatingTypeOverriding Operating mode override	Output operating mode override 0 = No operating mode override 1 = Boost 2 = Exercise 3 = Night purge 4 = Fan force
4	9103	fOutOperatingState Operating state	Output operating state 1 = Standby 2 = Control system 3 = Manual mode 6 = Fire emergency stop 7 = Frost protection 8 = Priming 11 = Night purge
5	9104	eOutVentilationType Type of ventilation	Output type of ventilation 0 = No ventilation 1 = Secondary air operation 2 = Outdoor air operation
6	9105	fOutTempSupply Actual supply air temperature	Measured value = Value /10, example: Value 185 ⇒ measured value = 18.5°C Value = 32767 = Measured value not available
7	9106	fOutTempOda Current outdoor temperature	Measured value = Value /10, example: Value 125 ⇒ measured value = 12.5°C Value = 32767 = Measured value not available
8	9107	fOutTempRoom Room temperature actual value	Measured value = Value /10, example: Value 225 ⇒ measured value = 22.5°C Value = 32767 = Measured value not available
9	9108	fOutTempReturnFlow Current return temperature	Measured value = Value /10, example: Value 335 ⇒ measured value = 33.5°C Value = 32767 = Measured value not available

Menu for connection to central BMS &gt; 'Connection to central BMS è Device =&gt; ...

no.	Address	Who	Notes
10	9109	fOutTempFlow Current flow temperature	Measured value = Value 1/10, example: Value 600 ⇒ measured value = 60°C Value = 32767 = Measured value not available
11	9110	fOutTempOffset Current room / supply air temperature offset	Offset = Value 1/10, example: Value 10 ⇒ Offset = 1°C Value = 32767 = Measured value not available
12	9111	bOutExtratime Overtime activation	Output overtime activation 0 = Disabled 1 = Enabled
13	9112	fOutTempRangeCooling Temperature upper limit, cooling	Temperature limit = Value 1/10, example: Value 420 ⇒ upper limit = 42°C
14	9113	fOutTempRangeHeating Temperature lower limit, heating	Temperature limit = Value 1/10, example: Value 180 ⇒ upper limit = 18°C
15	9114	fOutTempSetPointSupply Supply air temperature setpoint value	Supply air temperature setpoint value = Value 1/10, example: Value 250 ⇒ supply air temperature setpoint value = 25°C
16	9115	fOutFanLevel Fan stage	Output fan stage 2 = Stage 1 manual mode 3 = Stage 2 manual mode 4 = Stage 3 manual mode 5 = Stage 4 manual mode 6 = Stage 5 manual mode 8 = Stage 1 automatic mode 9 = Stage 2 automatic mode 10 = Stage 3 automatic mode 11 = Stage 4 automatic mode 12 = Stage 5 automatic mode
17	9116	fOutHumidityRoom Current room humidity	Room air humidity in % = Value, example: Value 50 ⇒ room air humidity = 50% Value 32767 = Measured value not available
18	9117	fOutAirQualityRoom Current indoor air quality	Indoor air quality in ppm or ppm CO <sup>2</sup> equivalent = Value, example: Value 580 ⇒ indoor air quality = 580ppm Value 32767 = Measured value not available
19	9118	fOutVolumeFlowOda Fresh air volume flow rate	Output current fresh air volume flow rate in [l/s]
20	9119	fOutVolumeFlowExhaust Extract air volume flow rate	Output of current extract air volume flow rate in [l/s]
21	9120	fOutAlarmA Alarm A consolidated alarm	Output consolidated alarm as bit string ☞ 'A alarm' on page 32
22	9121	fOutAlarmB Alarm B consolidated alarm	Output consolidated alarm as bit string ☞ 'B Alarm' on page 32
24	9123	bOutWindow Window contact	Output window contact 0 = Inactive 1 = Active
25	9124	bOutFire Fire alarm	Output fire emergency stop 0 = Inactive 1 = Active

no.	Address	Who	Notes
26	9125	fOutSystemDevices Number of devices in the system	Output of device number in the network Example 1 master + 1 slave output = 2
27	9126	eOutDemandRoom Room requirements	Output of heating and cooling requirements for room 1 = Room must be heated 2 = Room must be cooled
28	9127	eOutDemandValve Valve requirements	Output of heating and cooling requirements for implementing the supply air temperature 1 = Supply air is heated 2 = Supply air is cooled
29	9128	fOutValvePositionHeatingMaster Control input signal of master heating valve	Output control of heating valve = Value 1/10, example: Value = 400 ⇒ control input signal = 40 %
30	9129	fOutValvePositionCoolingMaster Control of master cooling valve	Output control of cooling valve = Value 1/10, example: Value = 400 ⇒ control input signal = 40 %
31	9130	fOutTempSupplySlave01 Supply air temperature slave 1	Display of current supply air temperature slave (x) = Value 1/10, example: Value 275 ⇒ measured value = 27.5°C Value = 32767 = Measured value not available
32	9131	fOutTempSupplySlave02 Supply air temperature slave 2	
33	9132	fOutTempSupplySlave03 Supply air temperature slave 3	
34	9133	fOutTempSupplySlave04 Supply air temperature slave 4	
35	9134	fOutTempSupplySlave05 Supply air temperature slave 5	
36	9135	fOutTempSupplySlave06 Supply air temperature slave 6	
37	9136	fOutTempSupplySlave07 Supply air temperature slave 7	
38	9137	fOutTempSupplySlave08 Supply air temperature slave 8	
39	9138	fOutTempSupplySlave09 Supply air temperature slave 9	
40	9139	fOutTempSupplySlave10 Supply air temperature slave 10	
41	9140	fOutValvePositionHeatingSlave01 Heating valve slave 1	Display of current control of heating valve slave (x) = Value 1/10, example: Value 250 ⇒ control input signal = 25% Value = 32767 = Measured value not available
42	9141	fOutValvePositionHeatingSlave02 Heating valve slave 2	
43	9142	fOutValvePositionHeatingSlave03 Heating valve slave 3	

Menu for connection to central BMS > 'Connection to central BMS è Device => ...

no.	Address	Who	Notes
44	9143	fOutValvePositionHeatingSlave04 Heating valve slave 4	
45	9144	fOutValvePositionHeatingSlave05 heating valve slave 5	
46	9145	fOutValvePositionHeatingSlave06 Heating valve slave 6	
47	9146	fOutValvePositionHeatingSlave07 heating valve slave 7	
48	9147	fOutValvePositionHeatingSlave08 Heating valve slave 8	
49	9148	fOutValvePositionHeatingSlave09 heating valve slave 9	
50	9149	fOutValvePositionHeatingSlave10 Heating valve slave 10	
51	9150	fOutValvePositionCoolingSlave01 Cooling valve slave 1	Display of current control of cooling valve slave (x) = Value 1/10, example: Value 650 ⇒ control input signal = 65% Value = 32767 = Measured value not available
52	9151	fOutValvePositionCoolingSlave02 Cooling valve slave 2	
53	9152	fOutValvePositionCoolingSlave03 Cooling valve slave 3	
54	9153	fOutValvePositionCoolingSlave04 Cooling valve slave 4	
55	9154	fOutValvePositionCoolingSlave05 Cooling valve slave 5	
56	9155	fOutValvePositionCoolingSlave06 Cooling valve slave 6	
57	9156	fOutValvePositionCoolingSlave07 Cooling valve slave 7	
58	9157	fOutValvePositionCoolingSlave08 Cooling valve slave 8	
59	9158	fOutValvePositionCoolingSlave09 Cooling valve slave 9	
60	9159	fOutValvePositionCoolingSlave10 Cooling valve slave 10	

### 4.5.3 'Connection to central BMS → Central BMS => device'

The following table shows all data points that can be sent from the central BMS to the device.

#### Note

For test purposes, entries can be made directly in the web browser if the central BMS has not yet been connected. For example, communication with the central BMS can be tested without the central BMS being completed. In some instances, data points are reset to the value 32767 after entry and processing. To check that a command has been taken over, the corresponding diagnostics page is provided.  
The prerequisite for the test via web browser is the activation of the Modbus interface for communication via the central BMS. If the BACnet interface is active, it is not possible to enter commands via the web browser.

no.	Address	Who	Notes
1	9000	eInOperatingMode Default operating mode	Default operating mode 1 = Off 2 = Automatic
2	9001	eInOperatingType Default operating mode	Specification of operating mode 1 = Standby 2 = Unoccupied 3 = Occupied
3	9002	eInOperatingTypOverinding Operating mode override	Default operating mode override 0 = No operating mode override 1 = Boost 2 = Exercise 3 = Night purge 4 = Fan Force (fume cupboard switching)
4	9003	fInPvTempOda current Outdoor temperature	Default current outdoor air temperature = Value 1/10, example: Value 125 ⇒ default = 12.5°C
5	9004	fInSpTempRangeCooling Temperature limit cooling	Default temperature limit cooling = Value 1/10, example: Value 225 ⇒ default = 22.5°C
6	9005	fInSpTempRangeHeating Temperature limit heating	Default temperature limit heating = Value 1/10, example: Value 218 ⇒ default = 21.8°C
7	9006	fInPvTempRoom Room temperature actual value	Default current room temperature = Value 1/10, example: Value 235 ⇒ default = 23.5°C
8	9007	fInSPTempRoom Room air temperature setpoint	Default room air temperature setpoint = Value 1/10, example: Value 220 ⇒ default = 22.0°C
9	9008	fInSpOffsetRoom Offset to the room temperature setpoint	Default offset to the room temperature setpoint = Value 1/10, example: Value 10 ⇒ Offset = 1°C
10	9009	fInSpTempSupplyAir Supply air temperature setpoint value	Transmission of supply air temperature setpoint value = Value 1/10, example: Value 230 ⇒ default = 23°C
11	9010	fInSpOffsetSupplyAir Offset to the supply air temperature setpoint	Default offset to the supply air temperature setpoint = Value 1/10, example: Value 10 ⇒ Offset = 1°C

no.	Address	Who	Notes
12	9011	fInPvHumRoom Current relative room air humidity	Default current relative room air humidity in % = Value, example: Value 45 ⇒ room air humidity = 45%
13	9012	eInChangeOver Changeover mode	Message on the medium 1 = Heat transfer fluid present 2 = Coolant present
14	9013	fInSpFanLevel Fan stage	Default fan stage 1 = Stage 1 2 = Stage 2 3 = Stage 3 4 = Stage 4 5 = Stage 5
15	9014	fInPvAqRoom Indoor air quality (internal)	Default indoor air quality
16	9015	fInPvAqOda Outdoor air quality (external)	Default outdoor air quality
17	9016	fInPvVolumeFlowDifference Volume flow rate difference	Default volume flow rate difference
18	9017	bInFire Fire emergency stop	Default fire emergency stop 0 = Inactive 1 = Active
19	9018	bInWindow Window contact	Default window contact 0 = Inactive 1 = Active
20	9020	bInExtratime Overtime	Overtime function activation 0 = Inactive 1 = Active
21	9021	bInFilterReset Default for filter reset	Resetting the filter change alert 0 = Inactive 1 = Active
22	9022	eInOdaAutomatic Default automatic fresh air system	Activation of the fresh air function 0 = Inactive 1 = Active



#### 4.5.4 Connection to central BMS via BACnet

##### 4.5.4.1 Protocol Implementation Conformance Statement (PICS)

The data points of the BACnet protocol are described in this chapter.

The BACnet capabilities of the FSL-CONTROL III controller are described below.

Date	- 2020-01-10
Vendor name	- Schneider Electric
Product name	- M172
Application software version	- 1.0
Firmware revision	- 596.9
BACnet Protocol Revision	- 12

##### Product description

- Schneider Electric BACnet IP and MS/TP Interface

##### BACnet Standardized Device Profile (Annex L):

- BACnet Advanced Application Controller (B-AAC)

##### List all BACnet Interoperability Building Blocks Supported (Annex K):

- Data Sharing-ReadProperty-B (DS-RP-B)
- Data Sharing-WriteProperty-B (DS-WP-B)
- Data Sharing-ReadPropertyMultiple-B (DS-RPM-B)
- Data Sharing-WritePropertyMultiple-B (DS-WPM-B)
- Data Sharing-COV-B (DS-COV-B)

##### Segmentation Capability

- Able to transmit segmented messages Window Size 1476 Byte/seg

##### Standard Object Types Supported

- Analogue Input
- Analogue Output
- Analogue Value
- Binary Value
- Calendar
- Device
- Multistate Input
- Multistate Value
- Notification class
- Schedule

##### Data Link Layer Options

- BACnet IP, 100 MBPS
- MS/TP master (Clause 9), baud rate(s): 9600, 19200, 38400, 56700, 76800

##### Device Address Binding

- Static device binding not supported

##### Networking Options

- BACnet/IP Broadcast Management Device (BBMD)  
The BBMD support registrations by Foreign Devices.

##### Network Security Options:

- Non-secure Device - is capable of operating without BACnet Network Security


##### Character Sets Supported

- Indicating support for multiple character sets does not imply that they can all be supported simultaneously.
  - ISO 8859-1

## Description of device object

Property	Remark / Value	RW
Object_Identifier	65536 + BACnet Identifier	RW-E
Object_Name	Default = "FSL-CONTROL III", BACnet ObjectName	RW-E
Object_Type	Device (8)	R
System_Status	OPERATIONAL (0)	R
Vendor_Name	"Schneider Electric"	R
Vendor_Identifier	10	R
Model_Name	M172	R
Firmware_Revision	"596.9"	R
Application_Software_Version	"1.0"	R
Protocol_Version 1 R	1	R
Protocol_Revision	12	R
Protocol_Services_Supported	read-property, write-property, device-communication-control, reinitialize-device, who-has, who-is	R
Protocol_Object_Types_Supported	DEVICE, ANALOG_INPUT,ANALOG_VALUE, BINARY_VALUE, MULTISTATE_INPUT,MULTI-STATE_VALUE	R
Object_List	device, analogue-input 0...50, analog value 0..13,	R
Max_APDU_Length_Accepted	binary-value 0 ...7, multistate_input 0...4; multistate-value 0...3	R
Segmentation_Supported	1476	R
APDU_Timeout	NO_SEGMENTATION (3)	R
Number_Of_APDU_Retries	3000	R
Device_Address_Binding	3	R
Database_Revision	-	R
Description Controller Type	0	R
Max_Master default	Default 127	RW-E
Max_Info_Frames	Default 1	RW-E

R:Read Property, W: Write Property, -E: Storage in EEPROM

 **Note**
**Object name**

*FSLCONTROLIII* is pre-set as the object name (Object\_Name).

↳ 3.1.2.11 'Interfaces' on page 25 .

**Object Identifier**

The object identifier is formed from the sum "65536" + BACnet identifier (address 17565).

**4.5.4.2 Communication from device to central BMS**

Display of all data points that can be transferred via BACnet from the device to the central building management system.

**Analogue Input Object**

Property	Remark / Value	RW
Object_Identifier	Analogue Input Value, instance 1 ... 50	R
Object_Name		R
Object_Type	ANALOG_INPUT_VALUE (0)	R
Present_Value		R
Status_Flags	IN_ALARM:	
Vendor_Identifier	FAULT:	
Model_Name	OVERRIDDEN:	
Firmware_Revision	OUT_OF_SERVICE:	
Event_State	NORMAL (0)	R
Out_Of_Service	FALSE (0)	R
Units		R

R:Read Property, W: Write Property

Object_Type	Instance	Object_Name	Object_Description_DE	Units	Initial Present_Value	Present_Value
AI	0	fOutFanLevel	Output fan stage 1 = 0_Manual 2 = 1_Manual 3 = 2_Manual 4 = 3_Manual 5 = 4_Manual 6 = 5_Manual 7 = 0_AUTO 8 = 1_AUTO 9 = 2_AUTO 10 = 3_AUTO 11 = 4_AUTO 12 = 5_AUTO	no units (95)	327.67	R
AI	1	fOutOperatingState	Output operating state 0 = Off 1 = Standby 2 = Control 3 = Manual 4 = Device Startup 5 = Shutdown 6 = Fire Protection 7 = Frost Protection 8 = Startup Circuitry 9 = Error 10 = Valve Kick 11 = Night Purge	no units (95)	327.67	R

Object_Type	Instance	Object_Name	Object_Description_DE	Units	Initial Present_Value	Present_Value
AI	2	fOutOperatingTypeOverriding	Output operating mode override 0 = None 1 = Boost 2 = Exercise 3 = Night Purge 4 = Fan Force	no units (95)	327.67	R
AI	3	fOutValvePositionCoolingSlave03	Output control of cooling valve slave 3	percent (98)	327.67	R
AI	4	fOutValvePositionHeatingSlave03	Output position of heating valve slave 3	percent (98)	327.67	R
AI	5	fOutTempSupplySlave03	Output supply air temperature slave 3	degrees Celsius (62)	327.67	R
AI	6	fOutTempSupplySlave02	Output supply air temperature slave 2	degrees Celsius (62)	327.67	R
AI	7	fOutValvePositionHeatingSlave02	Output position of heating valve slave 2	percent (98)	327.67	R
AI	8	fOutValvePositionCoolingSlave02	Output control of cooling valve slave 2	percent (98)	327.67	R
AI	9	fOutValvePositionCoolingSlave01	Output control of cooling valve slave 1	percent (98)	327.67	R
AI	10	fOutValvePositionHeatingSlave01	Output position of heating valve slave 1	percent (98)	327.67	R
AI	11	fOutTempSupplySlave01	Output supply air temperature slave 1	degrees Celsius (62)	327.67	R
AI	12	fOutAlarmB	Output consolidated alarm B	no units (95)	327.67	R
AI	13	fOutAlarmA	Output consolidated alarm A	no units (95)	327.67	R
AI	14	fOutValvePositionCoolingMaster	Output position of master cooling valve	percent (98)	327.67	R
AI	15	fOutValvePositionHeatingMaster	Output position of heating valve master	percent (98)	327.67	R
AI	16	fOutSystemDevices	Output number of connected devices	no units (95)	327.67	R
AI	17	fOutVolumeFlowExhaust	Output extract air flow rate	l/s (87)	65535	R
AI	18	fOutVolumeFlowOda	Output supply air flow rate	l/s (87)	65535	R
AI	19	fOutAirQualityRoom	Output air quality	parts per million (96)	65535	R
AI	20	fOutHumidityRoom	Output relative humidity	percent relative humidity (29)	327.67	R
AI	21	fOutTempSetPointSupply	Output supply air set-point temperature	degrees Celsius (62)	327.67	R
AI	22	fOutTempRangeHeating	Output temperature lower limit	degrees Celsius (62)	327.67	R

Object_Type	Instance	Object_Name	Object_Description_DE	Units	Initial Present_Value	Present_Value
AI	23	fOutTempRange-Cooling	Output temperature upper limit	degrees Celsius (62)	327.67	R
AI	24	fOutTempOffset	Output temperature offset	degrees Kelvin (63)	327.67	R
AI	25	fOutTempFlow	Output flow temperature	degrees Celsius (62)	327.67	R
AI	26	fOutTempReturnFlow	Output return temperature	degrees Celsius (62)	327.67	R
AI	27	fOutTempRoom	Output room temperature	degrees Celsius (62)	327.67	R
AI	28	fOutTempOda	Output outdoor air temperature	degrees Celsius (62)	327.67	R
AI	29	fOutTempSupply	Output supply air temperature	degrees Celsius (62)	327.67	R

**Binary Value**

Property	Remark / Value	RW
Object_Identifier	binary-output, instance 1 ... 7	R
Object_Name		R
Object_Type	BINARY_VALUE (5)	R
Present_Value	INACTIVE (0, Initial) / ACTIVE (1)	
Status_Flags	IN_ALARM: 0 FAULT: 0 OVERRIDDEN: 0 OUT_OF_SERVICE: 0	R
Event_State	NORMAL (0)	R
Out_Of_Service	FALSE (0)	R
Inactive_Text		
Active_Text		R

R: Read Property, W: Write Property, COVU: Unsolicited Change of Value Notification

Object_Type	Inst.	Object_Name	Object_Description_DE	Inactive_Text	Active Text	Present_Value
BV	5	bOutFire	Output fire emergency stop	"normal"	"fire"	R
BV	6	bOutWindow	Output window contact	"closed"	"open"	R
BV	7	bOutExtratime	Output overtime	"inactive"	"active"	R

**Multistate Input Object**

Property	Remark / Value	RW
Object_Identifier	Multistate-Input Value, instance 0 ... 4	R
Object_Name		R
Object_Type	MULTISTATE_INPUT_VALUE (7)	R
Present_Value	State	
Status_Flags	IN_ALARM: 0 FAULT: 0 OVERRIDDEN: 0 OUT_OF_SERVICE: 0	
Event_State	NORMAL (0)	
Out_Of_Service	FALSE (0)	
Number_Of_States		
State_Text		R

R: Read Property, W: Write Property, -E: Storage in EEPROM

Object_Type	Inst.	Object_Name	Object_Description_DE	Number_Of_States	State	Initial Present_Value	Present_Value
MI	0	eOutOperatingMode	Output operating mode	3	1	"Off"	R
					2	"Automatic"	
					3	"Manually"	
MI	1	eOutOperatingType	Output operating mode	4	1	"None"	R
					2	"Standby"	
					3	"Unoccupied"	
					4	"Occupied"	
MI	2	eOutVentilationType	Output type of ventilation	3	1	"None"	R
					2	"Secondary Air"	
					3	"Outside Air"	
MI	3	eOutDemandRoom	Room requirements	3	1	"None"	R
					2	"Heating"	
					3	"Cooling"	
MI	4	eOutDemandValve	Valve requirements	3	1	"None"	R
					2	"Heating"	
					3	"Cooling"	

#### 4.5.4.3 Communication from central BMS to device

Display of all data points that can be transferred via BACnet from the central building management system to the devices.

##### Analogue Value Object

Property	Remark / Value	RW
Object_Identifier	Analogue-Value, Instance 0 ... 13	R
Object_Name		R
Object_Type	ANALOG_VALUE (2)	R
Present_Value		R
Status_Flags	IN_ALARM: 0 FAULT: 0 OVERRIDDEN: 0 OUT_OF_SERVICE: 0	
Vendor_Identifier	NORMAL (0)	
Model_Name	FALSE (0)	
Firmware_Revision		
Event_State	Analogue-Value, Instance 0 ... 13	R
Out_Of_Service		R
Units		R

R:Read Property, W: Write Property

Object_Type	Instance	Object_Name	Object_Description_DE	Units	Initial Present_Value	Present_Value
AV	0	fInSpTempRange-Cooling	Default temperature limit cooling	degrees Celsius (62)	327.67	RW
AV	1	fInSpTempRange-Heating	Default temperature limit heating	degrees Celsius (62)	327.67	RW
AV	2	fInPvTempRoom	Default current room temperature	degrees Celsius (62)	327.67	RW
AV	3	fInSPTempRoom	Default room temperature setpoint value	degrees Celsius (62)	327.67	RW
AV	4	fInSpOffsetRoom	Default offset to room temperature setpoint value	degrees Kelvin (63)	327.67	RW
AV	5	fInSpTempSupply	Default supply air temperature setpoint value	degrees Celsius (62)	327.67	RW
AV	6	fInSpOffsetSupply	Default offset to supply air temperature setpoint value	degrees Kelvin (63)	327.67	RW
AV	7	fInPvHumidityRoom	Default relative room air humidity	percent relative humidity (29)	327.67	RW

Object_Type	Instance	Object_Name	Object_Description_DE	Units	Initial Present_Value	Present_Value
AV	8	flnSpFanLevel	Default fan stage 1 = Stage 1 2 = Stage 2 3 = Stage 3 4 = Stage 4 5 = Stage 5	no units (95)	327.67	RW
AV	9	flnPvAirQualityqRoom	Default air quality (room)	parts per million (96)	327.67	RW
AV	10	flnPvAirQualityOda	Default air quality (external)	parts per million (96)	327.67	RW
AV	11	flnPvVolumeFlowDifference	Default volume flow rate difference	l/s (87)	327.67	RW
AV	12	flnPvOperatingTypeOverriding	Default operating mode override 0 = Inactive 1 = Boost 2 = Exercise 3 = Night purge 4 = Fan force (fume cupboard switching)	no units (95)	327.67	RW
AV	13	flnPvTempOda	Default outdoor air temperature	degrees Celsius (62)	327.67	RW



*All offset values can be transmitted as signed integer!*

+1 K --> 1

-1 K --> -1



**Binary Value Objects**

Property	Remark / Value	RW
Object_Identifier	Binary-Value, instance 0 ... 7	R
Object_Name		R
Object_Type	BINARY_VALUE (5)	R
Present_Value	INACTIVE (0, Initial) / ACTIVE (1)	
Status_Flags	IN_ALARM: 0 FAULT: 0 OVERRIDDEN: 0 OUT_OF_SERVICE: 0	
Event_State	NORMAL (0)	R
Out_Of_Service	FALSE (0)	R
Units		R

R: Read Property, W: Write Property, COVU: Unsolicited Change of Value Notification

Object_Type	Inst.	Object_Name	Object_Description_DE	Inactive_Text	Active Text	Present_Value
BV	0	bInFire	Default fire emergency stop	"normal"	"fire"	RW
BV	1	bInWindow	Default window contact	"closed"	"open"	RW
BV	2	bInExtratime	Default overtime	"inactive"	"active"	RW
BV	3	bInFilterReset	Default filter change	"inactive"	"reset"	RW
BV	4	bInCondensation	Default condensate	"inactive"	"active"	RW

**Multistate Value**

Property	Remark / Value	RW
Object_Identifier	Multistate-Value, instance 0 ... 3	R
Object_Name		R
Object_Type	MULTISTATE_VALUE (9)	R
Present_Value	State	
Status_Flags	IN_ALARM: 0 FAULT: 0 OVERRIDDEN: 0 OUT_OF_SERVICE: 0	R
Event_State	NORMAL (0)	R
Out_Of_Service	FALSE (0)	R
Units R		R

R: Read Property, W: Write Property, -E: Storage in EEPROM

Object_Type	Inst.	Object_Name	Object_Description_DE	Number_of_States	State	State_Text	Present_Value
MV	0	eInOperatingMode	Default operating mode	3	1	"invalid"	RW
					2	"off"	
					3 (initial)	"automatic"	
MV	1	eInOperatingType	Default operating mode	4	1	"invalid"	RW
					2	"standby"	
					3	"unoccupied"	
					4	"occupied"	
MV	2	eInChangeOver	Default changeover	2	1	"invalid"	RW
					2	"warm water"	
					3	"cold water"	
MV	3	eInCovMode	Default COV Mode	4	1	"invalid"	RW-E
					2	"disabled"	
					3	"local broadcast"	
					4	"global broadcast"	
MV	4	eInOdaAutomatic	Fresh air	3	1	"invalid"	RW
					2	"inactive"	
					3	"active"	

## 5 Control panel

### 5.1 Overview of control panels




Fig. 28: Control panel with selector switch, for surface mounting, type: T760F1000 article number: M546FB8

- ① Fan stage selector
- ② Push button
- ③ LED
- ④ Setpoint value adjuster



Fig. 29: Control panel with selector switch, for surface mounting, type: WRF04 PSTD NTC20k 5k FS5 gn 5V SA, article number: A00000082515

- ① Fan stage selector
- ② Push button
- ③ LED
- ④ Setpoint value adjuster



Fig. 30: Control panel without selector switch, for surface mounting, type: Schneider STR 504 article number: M536BA4

- ② Push button
- ③ LED
- ④ Setpoint value adjuster




Fig. 31: Control panel without selector switch, for surface mounting, type: WRF04 PTD NTC 20k 5k gn, article number: A00000079777

- ② Push button
- ③ LED
- ④ Setpoint value adjuster

## Overview of control panels




Fig. 32: Control panel without selector switch, for flush mounting, suitable for switch programme Berker S.1, type: WRF07 PTD NTC20k BType6 5k gn, article number: A00000079778

- ② Push button
- ③ LED
- ④ Setpoint value adjuster




Fig. 34: Control panel without selector switch, for flush mounting, suitable for switch programme Berker Q.3, type: WRF07 PTD NTC20k BType6 5k gn, article number: A00000081579

- ② Push button
- ③ LED
- ④ Setpoint value adjuster




Fig. 33: "Fig. 34: Control panel without selector switch, for flush mounting, suitable for switch programme Busch Jäger Future linear type: WRF07 PTD NTC20k BType6 5k gn, article number: A00000079779"

- ② Push button
- ③ LED
- ④ Setpoint value adjuster




Fig. 35: Control panel without selector switch and setpoint value adjuster for flush mounting, suitable for switch programme Gira E2, type WRF06-TD-NTC20k, article number: A00000081503

- ② Push button
- ③ LED

## 5.2 Control panel settings

Function	Description	LED
Ventilation stages <sup>1</sup>	<p>With the aid of the stage selector, the ventilation stage can be freely selected. The following functions are available:</p> <ul style="list-style-type: none"> <li>■ Automatic (recommended), fan stages are automatically selected from the temperature control and air quality control (optional) -</li> <li>■ 0: The device switches to Standby mode</li> <li>■ 1: Fan stage 1 is selected</li> <li>■ 2: Fan stage 2 is selected</li> <li>■ 3: Fan stage 3 is selected</li> </ul> <p>Note: After activation of Standby mode and subsequent switch to a fan stage or Automatic, the ventilation unit must also be switched to Occupied (using the Occupancy button or central BMS).</p>	
Occupied/ Unoccupied <sup>2</sup>	<p>If you want to change the operating mode from 'Occupied' to 'Unoccupied' or vice versa, press the Occupancy push button briefly.</p> <p>This allows you, for example, to manually switch to 'Unoccupied' mode when the room is not occupied..</p> <p>Start-up delay: 1 to 2 minutes in summer, 6 to 7 minutes in winter.</p>	<p>Unoccupied: LED off</p> <p>Occupied: LED on</p>
Overtime <sup>2</sup>	<p>If you want to manually switch on the Overtime function while the system is in 'Unoccupied' mode, press the Occupancy push button briefly.</p> <p>This allows you to set the ventilation unit to 'Occupied' mode for a previously set period of time if, for example, overtime is required after regular office hours.</p> <p>The overtime period can be configured. After the set period the unit resumes the previous operating mode (RTC/central BMS).</p>	<p>Unoccupied: LED off</p> <p>Overtime: LED on</p>
Boost	<p>If you want to activate or deactivate rapid ventilation of the room, keep the Occupancy push button pressed (for 2-5 seconds).</p>	<p>LED flashes once per second</p>
Exercise	<p>For quiet work, the silence in the room is estimated. Pressing the Occupancy button (7-10 seconds), the Exercise function is activated.</p>	<p>LED in alternation 1 second ON, 1 second OFF.</p>
Changing the filter	<p>Double blinking of the LED indicates that a filter change is required (the number of operating hours can be configured; factory setting: after 2500 h).</p> <p>Units with differential pressure sensor: Activated if the preset maximum differential pressure or the preset number of operating hours is reached.</p> <p>To reset the number of operating hours, either keep the occupancy push button pressed (&gt; 10 sec) or use the web server</p>	<p>LED in alternation 1 second of double flashing, 1 second OFF.</p>
Alarm	<p>Frost alarm and hardware alarm.</p>	<p>LED flashes twice per second</p>

1) The stage selector is only available for the following control panels:

- Type T760F1000, article number: M546FB8

- Type WRF04 PSTD NTC20k 5k FS5 gn 5V SA, article number: A00000082515

2) The button on the control panel can either be used to switch between Occupied and Unoccupied or activate the overtime function. The configuration is carried out using the web browser and can be performed by personnel from TROX GmbH or TROX HGI

## 6 Index

### A

A alarm.....	32
Access data.....	27
Actuators.....	57
Air quality	
Control.....	38
Air quality control.....	19 , 38
Alarms.....	32

### B

BACnet.....	41
BACnet IP interface.....	15
BACnet MS/TP interface.....	15
B Alarm.....	32
Boost.....	21

### C

Central BMS.....	58
Clock.....	37
Comfort temperature range.....	17 , 22 , 24 , 36
Configuration.....	36 , 37
Connection to central BMS.....	58
Control	
Air quality.....	38
Humidity.....	39
Controller information.....	29
Control panel.....	7
Control variables.....	30
Copyright.....	3

### D

Defects liability.....	3
Device information.....	29
Device restart.....	39
Device status.....	29
Diagnosis.....	29

### E

Electrical installation.....	7
Exercise.....	21

### F

Fan control.....	38
Fan stages.....	19 , 31
Filter hours	
Reset.....	32
Free cooling .....	24
Frost protection.....	23
Functional description.....	17

### H

Hotline.....	3
Humidity	
Control.....	39

Humidity/air quality measured values .....	31
Humidity control.....	39
Hydraulic balancing.....	57

### I

Interfaces.....	25 , 39
BACnet.....	41
IP address.....	40
IP gateway.....	40
IP network mask.....	40
IP address.....	27 , 40
IP gateway.....	40
IP network mask.....	40

### L

Limitation of liability.....	3
------------------------------	---

### M

Main menu.....	29
Manual control.....	57
Manual mode.....	57
Minimum fan stages.....	22
Modbus address.....	39
Modbus RTU interface.....	15
Modbus TCP interface.....	15

### N

Network address.....	27
Night purge.....	21

### O

Occupied.....	21
Operating information.....	29
Operating mode override.....	20
Operating modes.....	20

### P

Password.....	27
---------------	----

### Q

Qualification.....	6
--------------------	---

### R

Remaining run times.....	33
Reset	
Filter hours.....	32
Reset filter hours.....	57
Room / supply air temperatures.....	30
Room temperature control.....	17

### S

Schedule.....	37
Secondary air function.....	22
Service.....	3
Settings SL1 connection X1 serial bus.....	39
Settings SL2 connection X2 serial bus.....	40
Signs.....	5

Slave devices.....	39	Type of ventilation.....	31
Software		<b>U</b>	
Web browser.....	27	Unoccupied.....	21
Staff.....	6	User name.....	27
Standby.....	21	<b>V</b>	
Supply air temperature limits.....	36	Ventilation information.....	29
Symbols.....	5	<b>W</b>	
System information.....	29	Warranty claims.....	3
<b>T</b>		Web browser	
Technical Service.....	3	Software.....	27
Temperature control.....	30	Weekly program.....	37
Temperature sensor offset.....	36	Winter compensation.....	22 , 36
Temperature setpoint values.....	36		
Terminal resistor.....	12		

**TROX<sup>®</sup> TECHNIK**

The art of handling air

TROX GmbH  
Heinrich-Trox-Platz  
47504 Neukirchen-Vluyn, Ger-  
many

Germany  
Phone: +49 (0) 2845 2020  
+49 2845 202-265  
E-mail: [trox@trox.de](mailto:trox@trox.de)  
<http://www.troxtechnik.com>

© TROX GmbH 2020